

INCH-POUND
------------

MIL-PRF-19207E  
SUPPLEMENT 1  
1 March 1999

## PERFORMANCE SPECIFICATION

### FUSEHOLDERS, EXTRACTOR POST TYPE, BLOWN FUSE INDICATING AND NONINDICATING, GENERAL SPECIFICATION FOR

This supplement forms a part of MIL-PRF-19207E, dated 1 March 1999.

#### SPECIFICATION SHEETS

MIL-PRF-19207/1G	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Types FHL10U and FHL10G.
MIL-PRF-19207/2F	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL11U and FHL11G.
MIL-PRF-19207/3G	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Types FHL12U and FHL12G.
MIL-PRF-19207/4H	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL13G.
MIL-PRF-19207/5H	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL14G.
MIL-PRF-19207/6L	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating and Nonindicating, Type FHL15G.
MIL-PRF-19207/7K	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL16G.
MIL-PRF-19207/8E	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Types FHL17G1 and FHL17G2.
MIL-PRF-19207/9J	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Types FHL18G1 and FHL18G2.
MIL-PRF-19207/10C	-	Fuseholders, Extractor Post Type, Nonindicating, Types FHN19G and FHN19W.
MIL-PRF-19207/11G	-	Fuseholder, Extractor Post Type, Blown Fuse Nonindicating, Type FHN20G.
MIL-PRF-19207/12D	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL22W.
MIL-PRF-19207/13E	-	Fuseholders, Extractor Post Type, Nonindicating, Type FHN23W.

MIL-PRF-19207E  
SUPPLEMENT 1

MIL-PRF-19207/16F	-	Fuseholders, Extractor Post Type, Nonindicating, Types FHN26G1, FHN26G2, and FHN26W.
MIL-PRF-19207/17E	-	Fuseholders, Extractor Post Type, Nonindicating, Types FHN28W and FHN28WB.
MIL-PRF-19207/18G	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL29G.
MIL-PRF-19207/19J	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL30G.
MIL-PRF-19207/20C	-	Fuseholders, Extractor Post Type, Nonindicating, Types FHN31G1 and FHN31G2.
MIL-PRF-19207/21H	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL32W.
MIL-PRF-19207/22G	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL33W.
MIL-PRF-19207/23H	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL34W.
MIL-PRF-19207/24H	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL35W.
MIL-PRF-19207/25D	-	Fuseholders, Extractor Post Type, Nonindicating, Types FHN41W and FHN41WB.
MIL-PRF-19207/26F	-	Fuseholders, Extractor Post Type, Nonindicating, Type FHN42W.
MIL-PRF-19207/28D	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL44G.
MIL-PRF-19207/29D	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHN45G.
MIL-PRF-19207/30C	-	Fuseholders, Extractor Post Type, Nonindicating, Types FHN46W and FHN46WB.
MIL-PRF-19207/31C	-	Fuseholders, Extractor Post Type, Nonindicating, Types FHN47W and FHN47WB.
MIL-PRF-19207/32C	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL48U.
MIL-PRF-19207/33C	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL49U.
MIL-PRF-19207/36B	-	Fuseholders, Extractor Post Type, Nonindicating, R.F. Shielded Type FHN55W.
MIL-PRF-19207/38B	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL57G.
MIL-PRF-19207/39B	-	Fuseholders, Extractor Post Type, Blown Fuse Indicating, Type FHL58G.

Preparing activity:  
DLA - CC

(Project 5920-0594)