

MIL-F-24646(SH)
 SUPPLEMENT 1
 30 November 1984

MILITARY SPECIFICATION

FUSE BOXES

This supplement forms a part of Military Specification MIL-F-24646(SH), dated 30 November 1984.

SPECIFICATION SHEETS

- MIL-F-24646/1(SH) - Fuse Boxes, Feeder Distribution, Totally Enclosed, 125 Volts, Alternating Current, Single and Three Phase Buses, Single Phase Branches, 0-30 Ampere Midget Fuses, Symbols 600, 601, 612.1, 613, 613.1 and 614.
- MIL-F-24646/2(SH) - Fuse Boxes, Feeder Distribution, Totally Enclosed, 125/250 Volts, Direct Current, Three Wire Buses, Two Wire Branches, 0-30 Ampere Midget Fuses, Symbols 609, 610 and 611.
- MIL-F-24646/3(SH) - Fuse Boxes, Feeder Distribution, Totally Enclosed, 125/250 Volts, Direct Current, Three Wire Buses, Two Wire Branches, 0-30 Ampere Fuses, Symbols 540, 541 and 542.
- MIL-F-24646/4(SH) - Fuse Boxes, Feeder Distribution, Totally Enclosed, 450 Volts, Alternating Current, Three Phase Buses, Single and Three Phase Branches, 0-30 and 31-60 Ampere Fuses, Symbols 543, 544, 545, 546 and 547.
- MIL-F-24646/5(SH) - Fuse Boxes, Feeder Distribution, Totally Enclosed, 500 Volts, Direct Current, Two Wire Buses, 0-30 and 31-60 Ampere Fuses, Symbols 626 and 627.
- MIL-F-24646/6(SH) - Fuse Boxes, Feeder Distribution, with Switches, Totally Enclosed, 125 Volts, Alternating Current, Single and Three Phase Buses, Single and Double Feeder, Single Phase Branches, 0-30 Ampere Midget Fuses and Snap Switches, Symbols 602, 603, 604, 605, 606, 615, 616 and 617.
- MIL-F-24646/7(SH) - Fuse Boxes, Feeder Distribution, Submersible (15 Feet), 125 Volts, Alternating Current, Single Phase Buses, 0-30 Ampere Midget Fuses, Symbols 635.1, 653.1 and 654.1.
- MIL-F-24646/8(SH) - Fuse Boxes, Feeder Distribution, Submersible (15 Feet), 125 Volts, Alternating Current, Three Phase Buses, Single Phase Branches, 0-30 Ampere Midget Fuses, Symbols 646.1 and 647.1.
- MIL-F-24646/9(SH) - Fuse Boxes, Feeder Distribution, Submersible (15 Feet), 250 Volts, Alternating Current, Single Phase Buses, 0-30 Ampere Fuses, Symbols 555.1, 556.1, 557.1, 558.1 and 559.1.
- MIL-F-24646/10(SH) - Fuse Boxes, Feeder Distribution, Submersible (15 Feet), 250 Volts, Alternating Current, Three Phase Buses, Single and Three Phase Branches, 0-30 Ampere Fuses, Symbols 560.1, 561.1, 562.1 and 563.1.

FSC 5920,
 6110

MIL-F-24646(SH)
SUPPLEMENT 1

- MIL-F-24646/11(SH) - Fuse Boxes, Feeder Distribution, with Switches, Watertight (3 Feet), 125 Volts, Alternating Current, Single and Three Phase Buses, Single and Double Feeders, Single Phase Branches, 0-30 Ampere Midget Fuses, and Snap Switches Symbols 645, 645.1, 649.1 and 650.1.
- MIL-F-24646/12(SH) - Fuse Boxes, Feeder Distribution, with Switches, Watertight (3 Feet), 125 Volts, Alternating Current, Single or Three Phase Buses, Single Phase Branches, Interlocking Fuse Cover, 0-30 Ampere Fuses, and Snap Switches, Symbols 644 and 648.
- MIL-F-24646/13(SH) - Fuse Boxes, Feeder Distribution, Submersible (15 Feet), 500 Volts, Alternating Current, Three Phase Buses, Single and Three Phase Branches, 0-30 Ampere Fuses with Fuse Puller, Symbols 568.1, 569.1, 570.1 and 571.1.
- MIL-F-24646/14(SH) - Fuse Boxes, Feeder Junction, Totally Enclosed, 250 Volts, Alternating Current, Three Phase Buses, Single and Three Phase Branches, 0-30 and 31-60 Ampere Fuses, Symbols 680 and 681.1.
- MIL-F-24646/15(SH) - Fuse Boxes, Feeder Junction, Submersible (15 Feet), 250 Volts, Alternating Current, Feed Through Twin Conductors, Single and Three Phase Buses, Single and Three Phase Branches, 0-30 and 31-60 Ampere Fuses, Symbols 685.1, 686.1, 691.1 and 692.1.
- MIL-F-24646/16(SH) - Fuse Boxes, Feeder Junction, Submersible (15 Feet), 250 Volts, Alternating Current, Single Phase Buses, 0-30, 31-60, 61-100 and 101-200 Ampere Fuses, Symbols 687.1, 688.1, 689.1 and 690.1.
- MIL-F-24646/17(SH) - Fuse Boxes, Feeder Junction, Submersible (15 Feet), 500 Volts, Alternating Current, Three Phase Buses, 0-30 Ampere Fuses, Symbol 693.1.
- MIL-F-24646/18(SH) - Fuse Boxes, Branch Junction, Submersible (15 Feet), 125 Volts, Two Conductors, 0-30 Ampere Midget Fuses, Symbol 671.1.

Preparing activity:
Navy - SH