INCH-POUND

MIL-DTL-24646A SUPPLEMENT 1 20 March 2001

DETAIL SPECIFICATION

FUSE BOXES, GENERAL SPECIFICATION FOR

This supplement forms a part of MIL-DTL-24646A, dated 26 February 2001.

SPECIFICATION SHEETS

MIL-F-24646/1	-	Fuse Boxes, Feeder Distribution, Totally Enclosed, 125 Volts, Alternating Current, Single and Three Phase Buses, Single Phase Branches, 0-30 Ampere Midget Fuses, Symbols 600, 601, 612.1, 613, 613.1, and 614.
MIL-F-24646/2	-	Fuse Boxes, Feeder Distribution, Totally Enclosed, 125/250 Volts, Direct Current, Three Wire Buses, Two Wire Branches, 0-30 Ampere Midget Fuses, Symbols 609, 610, and 611.
MIL-F-24646/3	-	Fuse Boxes, Feeder Distribution, Totally Enclosed, 125/250 Volts, Direct Current, Three Wire Buses, Two Wire Branches, 0-30 Ampere Fuses, Symbols 540, 541, and 542.
MIL-F-24646/4	-	Fuse Boxes, Feeder Distribution, Totally Enclosed, 450 Volts, Alternating Current, Three Phase Buses, Single and Three Phase Branches, 0-30 and 31-60 Ampere Fuses, Symbols 543, 544, 545, 546, and 547.
MIL-F-24646/6	-	Fuse Boxes, Feeder Distribution, with Switches, Totally Enclosed, 125 Volts, Alternating Current, Single and Three Phase Buses, Single and Double Feeder, Single Phase Branches, 0-30 Ampere Midget Fuses and Snap Switches, Symbols 602, 603, 604, 605, 606, 615, 616, and 617.
MIL-F-24646/7	-	Fuse Boxes, Feeder Distribution, Submersible (15 Feet), 125 Volts, Alternating Current, Single Phase Buses, 0-30 Ampere Midget Fuses, Symbols 635.1, 653.1, 557.1, and 654.1.
MIL-F-24646/8	-	Fuse Boxes, Feeder Distribution, Submersible (15 Feet), 125 Volts, Alternating Current, Three Phase Buses, Single Phase Branches, 0-30 Ampere Fuses, Symbols 646.1 and 647.1.
MIL-F-24646/9	-	Fuse Boxes, Feeder Distribution, Submersible (15 Feet), 250 Volts, Alternating Current, Single Phase Buses, 0-30 Ampere Fuses, Symbols 555.1, 556.1, 557.1, 558.1, and 559.1.
MIL-F-24646/10	-	Fuse Boxes, Feeder Distribution, Submersible (15 Feet), 250 Volts, Alternating Current, Three Phase Buses, Single and Three Phase Branches, 0-30 Ampere Fuses, Symbols 560.1, 561.1 and 563.1.

MIL-DTL-24646A SUPPLEMENT 1

MIL-F-24646/11	-	Fuse Boxes, Feeder Distribution, with Switches, Watertight, (3 Feet), 125 Volts, Alternating Current, Single and Three Phase Buses, Single and Double Feeders, Single Phase Branches, 0-30 Ampere Midget Fuses, and Snap Switches, Symbols 645, 645.1, 649.1 and 650.1.
MIL-F-24646/14	-	Fuse Boxes, Feeder Junction, Totally Enclosed, 250 Volts, Alternating Current, Three Phase Buses, Single and Three Phase Branches, 0-30 and 31-60 Ampere Fuses, Symbols 680 and 681.1.
MIL-F-24646/15	-	Fuse Boxes, Feeder Junction, Submersible (15 Feet), 250 Volts, Alternating Current, Feed Through Twin Conductors, Single and Three Phase Buses, Single and Three Phase Branches, 0-30 and 31-60 Ampere Fuses, Symbols 685.1, 686.1, 691.1, and 692.1.
MIL-F-24646/17	-	Fuse Boxes, Feeder Junction, Submersible (15 Feet), 500 Volts, Alternating Current, Three Phase Buses, 0-30 Ampere Fuses, Symbol 693.1.
MIL-F-24646/18	-	Fuse Boxes, Branch Junction, Submersible (15 Feet), 125 Volts, Two Conductors, 0-30 Ampere Midget Fuses, Symbol 671.1.

Preparing activity: DLA - CC

(Project 5920-0671-99)