

NOT MEASUREMENT  
SENSITIVE

MIL-L-8031E(USAF)  
10 May 1991  
Superseding  
MIL-L-8031D(USAF)  
1 June 1975

**MILITARY SPECIFICATION  
LIST OF APPLICABLE PUBLICATIONS (LOAP),  
PREPARATION OF**

This specification is approved for use by the Department of the Air Force, and is available for use by all Departments and Agencies of the Department of Defense.

**1. SCOPE.**

1.1 Scope. This specification covers the detail requirements for the preparation of list of applicable publications, referred to throughout this specification as the LOAP. In addition to 'paper' delivery, this specification provides for electronic delivery of data through the use of the Document Type Definition (DTD) contained in Appendix A.

**2. APPLICABLE DOCUMENTS.**

**2.1 Government documents.**

2.1.1 Specifications, standards and handbooks. The following specifications, standards and handbooks form a part of this document to the extent specified herein. Unless otherwise specified, the issues of these documents are those listed in the

Beneficial comments (recommendations, additions, deletions) and any pertinent data which may be of use in improving this document should be addressed to: HQ AFLC/ENCS, Wright-Patterson AFB, OH 45433-5000 by using the self addressed Standardization Document Improvement Proposal (DD Form 1426) appearing at the end of this document or by letter.

**AMSC F6135**

**AREA TMSS**

**Distribution Statement A.** Approved for public release; distribution is unlimited.

## MIL-L-8031E(USAF)

issue of the Department of Defense Index of Specifications and Standards (DODISS) and supplement thereto, cited in the solicitation (see 6.2).

## SPECIFICATIONS

## Military

MIL-M-38784      Manuals, Technical: General Style and Format Requirements

MIL-P-38790      Printing Production of Technical Manuals: General Requirements for

(Unless otherwise indicated, copies of federal and military specifications, standards and handbooks are available from the Standardization Documents Order Desk, Building 4D, 700 Robbins Avenue, Philadelphia, PA 19111-5094.)

2.1.2 Other Government documents, drawings and publications.

The following other Government documents, drawings and publications form a part of this document to the extent specified herein. Unless otherwise specified, the issues are those cited in the solicitation (see 6.2).

## PUBLICATIONS

## Air Force Technical Manuals

TO 0-1-series      Technical Order Index

(Copies of documents required by contractors in connection with specific procurement functions should be obtained from the acquiring activity or as directed by the contracting officer.)

2.2 Order of precedence. In the event of a conflict between the text of this document and the references cited herein, the text of this document takes precedence. Nothing in this document, however, supersedes applicable laws and regulations unless a specific exemption has been obtained.

## 3. REQUIREMENTS.

3.1 Preparation. The general manner of preparation shall be in accordance with MIL-M-38784 and MIL-P-38790. The manual shall be prepared in 8 1/2 by 11 inch size. Unless otherwise specified,

## MIL-L-8031E(USAF)

Chapters 1 and 2 shall be double column format. When specified, they shall be single column format. Appendix A provides the DTD for electronic delivery of the LOAP.

3.2 Content and arrangement. The LOAP shall be arranged as follows.

Front Matter

Chapter 1 - Technical Manuals

Chapter 2 - Part Number to Technical Order Number

3.2.1 Front matter. Front matter shall consist of a title page, list of effective pages, verification status page (when applicable), table of contents and foreword in accordance with MIL-M-38784. See Figure 1 for an example table of contents. See Figure 2 for an example foreword.

3.2.2 Chapter 1 - Technical Manuals. This chapter shall include all technical manuals (index type, general and technical, including checklists, inspection work cards, inspection sequence charts, work unit code manuals, etc.) applicable to the specific equipment covered by the publication, including installed and support equipment. These listings shall also include commercial manuals and unpublished technical manuals being procured or prepared which have been assigned technical manual identification numbers. Supplemental manuals shall be included, but the type supplements identified in 3.4 shall not be included.

3.2.2.1 Technical manual listings (see Figure 3). The listings shall be in alphanumeric sequence, single position at a time (except as specified in 3.2.2.1.1), and under main series and subseries headings. However, technical manual identification numbers beginning with numeral 1 through 9 shall be considered to be preceded by a space; thus, TO 2J-TF39-2 shall be treated as 'space 2J-TF39-2' in order to precede TO 11A15-1-2. The main series headings used shall conform to the titles of the applicable numerical indexes listed in TO 0-1-01. The subseries headings used shall be those applicable in the current issue of the various numerical indexes (TO 0-1-1-1 thru -5, and 0-1-2 thru -51). Examples of main series and subseries headings are:

a. Aircraft Publications (1- Category)

- (1) General Aircraft
- (2) General Engineering Manuals
- (3) Weight and Balance

## MIL-L-8031E(USAF)

- (4) Air Refueling
- (5) Maintenance Analysis and Structural Integrity Information System
- (6) Aircraft Battle Damage Repair
- (7) Bomber Aircraft; Cargo/Transport Aircraft and Special Electronic Aircraft; Fighter Aircraft; Attack, Helicopter, Observation, Trainer and Utility Aircraft

b. Airborne Engines and Associated Equipment Publications  
(2- Category)

- (1) General Aircraft Engines
- (2) Gas Turbine Engines
- (3) Jet Engines
- (4) Booster and Rocket Engines
- (5) Reciprocating Engines

c. Fuel, Oil and Propellant Handling Equipment (37- Category)

- (1) Fuel and Oil Handling Equipment
- (2) Propellant Storage and Handling Equipment
- (3) Associated Equipment

d. Automatic Test Systems (51- Category)

- (1) General Automatic Test Systems
- (2) Computer Operated Test Stations
- (3) Aircraft Engines (Test Stations)
- (4) Navigation Instruments (Test Stations)
- (5) Radar Equipment (Test Stations)
- (6) GPATS Master Hardware
- (7) Test Guidance Equipment

3.2.2.1.1 Whole numbers. Numbers which are not separated by dashes, letters or other symbols shall be treated as whole (one) numbers. For example: the listing for TO 33D7-3-193-7-1 would precede the listing for TO 33D7-10-185-1, the listing for TO 33D7-6-89-1 would precede the listing for TO 33D7-6-136-1, etc.

3.2.2.2 Column heads (see Figure 3). Column headings shall be as follows:

TO NUMBER	TITLE	TYPE	TO NUMBER	TITLE	TYPE
-----------	-------	------	-----------	-------	------



## MIL-L-8031E(USAF)

any other facilities suitable for the performance of the inspection requirements specified herein, unless disapproved by the Government. The Government reserves the right to perform any of the inspections set forth in this specification where such inspections are deemed necessary to ensure supplies and services conform to the prescribed requirements.

**4.1.1 Responsibility for compliance.** All items shall meet all requirements of Sections 3 and 5. The inspection set forth in this specification shall become a part of the contractor's overall inspection system or quality program. The absence of any inspection requirements in the specification shall not relieve the contractor of the responsibility of ensuring that all products or supplies submitted to the Government for acceptance comply with all requirements of the contract. Sampling inspection, as part of manufacturing operations, is an acceptable practice to ascertain conformance to requirements, however, this does not authorize submission of known defective material, either indicated or actual, nor does it commit the Government to accept defective material.

**4.2 Quality conformance inspection.** Material furnished in accordance with this specification shall be inspected by the contractor for conformance to the applicable requirements of this document in accordance with MIL-M-38784, MIL-P-38790 and, when a contractual requirement, MIL-M-85337.

**4.3 Government inspection.** Material furnished in accordance with this specification shall be subject to inspection, verification and approval or disapproval by the Government as specified by the terms of the contract. Inspection/verification will be performed by the Government prior to acceptance.

**5. PACKAGING.**

**5.1 Packaging requirements.** Packaging shall be in accordance with MIL-M-38784.

**6. NOTES.**

(This section contains information of a general or explanatory nature that may be helpful, but is not mandatory.)

**6.1 Intended use.** The technical manuals prepared in accordance with the requirements of this specification are intended to enable personnel to select publications pertinent to the weapon, system, equipment or vehicle to which the publication applies.

MIL-L-8031E(USAF)

6.2 Acquisition requirements. Acquisition documents must specify the following:

- a. Title, number, and date of this document.
- b. Issue of the DODISS to be cited in the solicitation, and if required, the specific issue of individual documents referenced (2.1.1, 2.1.2).
- c. If Chapters 1 and 2 shall be single column format (3.1).
- d. If Chapter 2 shall not be included (3.2.3).
- e. If responsibility for inspection shall be other than as specified in this document (4.1).

6.3 Technical manual acquisition. To acquire the technical manuals described herein, this specification must be listed in AF TMCR TM-86-01, which in turn is listed in the Contract Data Requirements List (DD Form 1423), except where DOD FAR Supplement 27.475-1 exempts the requirement for a DD Form 1423.

6.4 Subject term (key word) listing.

LOAP

Publications, List of Applicable

6.5 Changes from previous issue. Marginal notations are not used in this revision to identify changes with respect to the previous issue due to the extensiveness of the changes.

Custodian:  
Air Force - 16

Preparing Activity:  
Air Force - 16

Review Activities:  
Air Force - 01, 10, 16, 70, 71,  
80, 82, 84, 99

(Project TMSS-F529)

MIL-L-8031E(USAF)

TO 1X-XXX-01

## TABLE OF CONTENTS

Chapter	Page	Chapter	Page
FOREWORD .....	ii	14- Deceleration Devices and Personal and Survival Equipment Publications .....	1-36
1 TECHNICAL ORDERS .....	1-1	15- Aircraft and Missile Temperature Control, Pressurizing, Air Conditioning, Heating, Ice Eliminating and Oxygen Equipment Publications.....	1-37
0- Index Type Publications .....	1-1	16- Airborne Mechanical Equipment Publications.....	1-39
00- General Technical Orders .....	1-1	21- Guided Missiles Publications .....	1-42
1- Aircraft Publications .....	1-1	22- Aerospace Vehicles Publications .....	1-46
2- Airborne Engines and Associated Equipment Publications .....	1-6	32- Standard and Special Tools Publications .....	1-47
4- Aircraft Landing Gear Publications.....	1-10	33- Test Equipment Publications.....	1-49
5- Airborne Instruments Publications .....	1-12	42- Coating, Cleaning and Sealing Compounds and Fuels, Gases, Lubricants, Chemicals and Materials Publications .....	1-52
6- Aircraft and Missile Fuel Systems Publications.....	1-16	44- Common Hardware Equipment Publications.....	1-54
7- Airborne Engine Lubricating Systems Publications .....	1-18	49- Optical Instruments, Timekeeping and Navigation Equipment Publications.....	1-56
8- Airborne Electrical Systems Publications .....	1-19		
9- Aircraft and Missile Hydraulic, Pneumatic and Vacuum Systems Publications.....	1-21	2 EQUIPMENT PART NUMBER TO TECHNICAL MANUAL NUMBER.....	2-1
11- Armament Equipment Publications.....	1-23		
12- Airborne Electronic Equipment Publications .....	1-28		
13- Aircraft Furnishings and In-Flight Feeding Equipment, Cargo Loading, Aerial Delivery and Recovery Equipment, Aircraft Fire Detection and Extinguishing Equipment Publications.....	1-35		

FIGURE 1. Example table of contents.



MIL-L-8031E (USAF)

TO 1E-3A-01

## FOREWORD

### 1. CONTENTS.

This list of applicable publications contains a complete listing of technical order system publications applicable to the E-3A aircraft. The words "complete listing" refer to technical orders required at sites, bases, overhaul depots and manufacturer plants to operate and maintain the aircraft including engines, accessories, installed equipment.

### 2. PURPOSE.

The purpose of this technical order is to enable concerned personnel to select and become familiar with publications pertinent to the E-3A. This technical order eliminates the need for compilation of similar data by individual service activities. Included in this technical order are technical orders required for limited technical order files, publications requirement tables, etc.

### 3. ARRANGEMENT.

3.1 Technical Order Listings. Publications in this technical order are listed in alpha numerical order and under classification headings corresponding to those contained in the technical order numerical indexes. Supplementary data are provided in the format columns to portray publication type.

#### NOTE

Before submitting requisition, refer to TO 0-1-series indexes to ascertain the date, status, availability, and security classification of publications listed herein.

3.2 Publication Titles. The publication titles appearing in this technical order conform, as nearly as possible, to those contained in the numerical indexes of technical publications.

### 4. ALPHANUMERICAL SEQUENCE.

4.1 Technical Order and Part Number Arrangement. Technical order and part number arrangement in this publication begin in the extreme left-hand position and continue from left to right until all alphanumerics are arranged in sequence. Technical order numbers beginning with the numerals 1 through 9 shall be considered to be preceded by a space. Therefore, TO 6J12-9-13 shall be treated as TO space 6J12-9-13 in order to precede TO 11A2-5-2-7.

4.2 First Position Order of Precedence. The order of precedence in beginning the technical order or part number arrangement on the extreme left-hand (first) position is as follows:

Letters:	A Through Z
Numbers:	0 Through 9

4.3 Continuing Order of Precedence. The order of precedence in continuing the alpha numeric arrangement on the second and succeeding position of the number from left to right is as follows:

Space (Blank)	Comma(,)
Point (Period) (.)	Pound (#)
Coml. at (@)	Parenthesis()
Dash(-)	Plus(+)
Asterisk (*)	Letters A Through Z
Diagonal Slant (/)	Numbers 0 Through 9
Ampersand (&)	

#### NOTE

Spaces, diagonals, periods, dashes, asterisks, commas, and parentheses do not appear in the extreme left-hand position, however, they are used in the second and succeeding positions and take precedence over letters and numerals as indicated above. Refer to paragraph 4.1 for exception.

4.4 Sample List. The following sample list of technical orders and part numbers is in the arrangement that will be followed in this publication:

TO NOS.	PART NOS.
1E-3A-2-110-1	TYPE AN/APM-67
1E-3A-10	TYPE AN/APM-129
1E-3A-36	50C7023-9
9H8-14-17-3	50C7023-11
9H8-14-169-4	50C7023-12

### 5. EXPLANATION OF SYMBOLS USED.

The following letters and abbreviations are used in this technical order.

CM	Commercial Manual
D	Depot
I	Informative
IM	Intermediate Maintenance
IN	Index
M	Manual
M-W	Manual in which Winterization Instructions are included
OI	Organizational/Intermediate
OM	Organizational Maintenance
PM	Preliminary Manual

### 6. UPDATES.

Recommendations proposing changes to this manual should be submitted on AFTO Form 22 in accordance with TO 00-5-1 to (appropriate agency).

II

FIGURE 2. Example foreword.

MIL-L-8031E (USAF)

T.O. 1E-3A-01

# CHAPTER 1 TECHNICAL MANUALS

TO NUMBER	TITLE	TYPE	TO NUMBER	TITLE	TYPE
<b>INDX-TYPE PUBLICATIONS (0- CATEGORY)</b>			1-1-8	APPLICATION AND REMOVAL OF ORGANIC COATINGS AEROSPACE AND NONAEROSPACE EQUIPMENT	M
0-1-SERIES	NUMERICAL INDEX/ALPHABETICAL INDEX AND CROSS REFERENCE TABLE	IN	1-1-17	STORAGE OF AIRCRAFT AND MISSILE SYSTEMS	M
0-2-1	ALPHABETICAL INDEX-ALPHABETICAL LISTING OF EQUIPMENT TO TECHNICAL PUBLICATION NUM- BER GROUPS	IN	1-1-19	INSPECTION, TEST AND REPLACEMENT OF VIBRATION ISOLATORS ON EQUIPMENT IN AIRCRAFT	M
0-4-2	CROSS REFERENCE TABLE OF TCTO NUMBERS TO APPLICABLE DATA CODE NUMBERS	IN	1-1-24	MAINTENANCE, REPAIR AND ELECTRICAL REQUIREMENTS FOR FIBERGLASS AIRBORNE RADOMES	I
0-4-6-1	NUMERICAL CROSS REFERENCE INDEX - EQUIPMENT NUMBERS TO TECHNICAL ORDER NUMBERS. THIS TECHNICAL ORDER WILL BE PRINTED FOR USE IN STANDARD AIR FORCE TECHNICAL ORDER BINDERS AND WILL CONTAIN LISTINGS IDENTICAL TO THOSE IN MICROFILM TO 0-4-6-2. QUESTIONS OF A GENERAL NATURE SHOULD BE DIRECTED TO OC-ALC/MEDUA QUESTIONS ABOUT A SPECIFIC TECHNICAL ORDER SHOULD BE DIRECT TO MMEOT SECTION AT THE PRIME ALC INDICATED FOR THAT LISTING. DO NOT SUBMIT AFTO FORMS 22 ON THIS PUBLI- CATION	IN	1-1-25	INSPECTION OF FABRIC COVERED SURFACES WITH PORTABLE AND/OR MULLENS TESTER	I
<b>GENERAL TECHNICAL ORDERS (00- CATEGORY)</b>			1-1-131	TABLE OF DIMENSIONS FOR USAF AIRCRAFT	I
00-5-1	AF TECHNICAL ORDER SYSTEM	I	1-1-300	ACCEPTANCE/FUNCTIONAL CHECK FLIGHT AND MAINTENANCE OPERATIONAL CHECKS	I
00-5-2	TECHNICAL ORDER DISTRIBUTION SYSTEM	I	1-1-312	USE OF HIGH PRESSURE AIR AND NITROGEN - ALL AIRCRAFT	I
00-5-15	AF TIME COMPLIANCE TECHNICAL ORDER SYSTEM	I	1-1-638	EXPEDITIOUS REPAIR AND DISPOSAL OF AEROSPACE VEHICLES	I
00-20-SERIES	MAINTENANCE MANAGEMENT SYSTEM - GENERAL	I	1-1-641	MINIMUM EQUIPMENT REQUIREMENTS FOR OVER WATER, ARCTIC, AND DESERT-TROPIC FLIGHTS	M
00-25-SERIES	MISCELLANEOUS TECHNICAL ORDERS - GENERAL	I	1-1-655	RESTRICTED USE OF HIGH POTENTIAL VOLTAGE TESTING APPARATUS ON AIRCRAFT CONTAINING FUEL	I
00-25-06-SERIES	WORK UNIT CODE MANUAL	I	1-1-688	USE OF ELECTRICAL EQUIPMENT IN HAZARDOUS AREAS (AIRCRAFT HANGAR, RAMP, AIRCRAFT SERVICE AREA)	I
00-25-113-SERIES	CONSERVATION, SEGREGATION AND DISPOSAL OF CRITICAL ALLOYS AND PRECIOUS METALS	I	1-1-689	PREVENTION AND CONTROL OF CORROSION AND FUNGUS IN COMMUNICATION, ELECTRICAL, METEOROLOGICAL, AND AVIONICS EQUIPMENT	M
00-25-113-E3	CRITICAL ALLOYS AND PRECIOUS METALS PARTS LIST (BOEING AEROSPACE COMPANY)	I	<b>GENERAL ENGINEERING MANUALS</b>		
00-25-234	GENERAL SHOP PRACTICE REQUIREMENTS FOR THE REPAIR, MAINTENANCE, AND TEST OF ELECTRONIC EQUIPMENT (PHILCO CORP.)	M	1-1A-1	ENGINEERING HANDBOOK SERIES FOR AIRCRAFT REPAIR - GENERAL MANUAL FOR STRUCTURAL REPAIR	M
00-25-245	OPERATIONAL INSTRUCTIONS - TESTING AND INSPECTION PROCEDURES FOR PERSONNEL SAFETY AND RESCUE EQUIPMENT (WY-ALC)	M	1-1A-8	ENGINEERING MANUAL SERIES - AIRCRAFT AND MISSILE REPAIR - STRUCTURAL HARDWARE	M
00-36-SERIES	ADMINISTRATIVE TECHNICAL ORDERS	I	1-1A-9	ENGINEERING SERIES FOR AIRCRAFT REPAIR AEROSPACE METALS - GENERAL DATA AND USAGE FACTORS	M
00-80-SERIES	SPECIAL TECHNICAL ORDERS	I	1-1A-12	ENGINEERING MANUAL SERIES FOR AIRCRAFT REPAIR - FABRICATION, MAINTENANCE AND REPAIR OF TRANSPARENT PLASTICS	M
00-86-SERIES	PROTECTIVE PACKAGING AND PRESERVATION PACKAGING - GENERAL	I	1-1A-14	INSTALLATION PRACTICES FOR AIRCRAFT ELECTRIC AND ELECTRONIC WIRING	I
00-110N-2	RADIOACTIVE WASTE DISPOSAL	I	1-1A-15	GENERAL MAINTENANCE INSTRUCTIONS FOR SUPPORT EQUIPMENT	M
00-110N-3	REQUISITION, HANDLING, STORAGE AND IDENTIFICATION OF RADIOACTIVE MATERIAL	I	<b>WEIGHT AND BALANCE</b>		
<b>AIRCRAFT PUBLICATIONS (1- CATEGORY)</b>			1-1B-40	WEIGHT AND BALANCE DATA	M
<b>GENERAL AIRCRAFT</b>			1-1B-50	WEIGHT AND BALANCE	M
1-1	TCTO SERIES	I	<b>AIR REFUELING</b>		
1-1-1	CLEANING OF AEROSPACE EQUIPMENT	I	1-1C-1	FLIGHT MANUAL - BASIC FLIGHT CREW AIR REFUELING PROCEDURES	M
1-1-2	CORROSION PREVENTION AND CONTROL FOR AEROSPACE EQUIPMENT	I	1-1C-1-27	FLIGHT MANUAL - FLIGHT CREW AIR REFUELING PROCEDURES	M
1-1-3	PREPARATION, INSPECTION AND REPAIR OF AIRCRAFT FUEL, OIL AND WATER ALCOHOL CELLS AND INTEGRAL TANKS	M	<b>SPECIAL ELECTRONIC AIRCRAFT</b>		
1-1-4	EXTERIOR FINISHES - INSIGNIA AND MARKINGS APPLICABLE TO USAF AIRCRAFT	M	1E-3A-01	LIST OF APPLICABLE PUBLICATIONS	I
			1E-3A-06	WORK UNIT CODE MANUAL	I

1-1

FIGURE 3. Example chapter 1 pages.

MIL-L-8031E(USAF)

TO 1B-52G-01

# CHAPTER 1 TECHNICAL MANUALS

TO NUMBER	TITLE	TYPE	TO NUMBER	TITLE	TYPE
<b>INDEX-TYPE PUBLICATIONS</b> (0- CATEGORY)			1-1-26	AIRCRAFT/STORES COMPATIBILITY MANUAL-B-52	M
0-1-SERIES	NUMERICAL INDEX/ALPHABETICAL INDEX AND CROSS REFERENCE TABLE	IN	1-1-300	ACCEPTANCE/FUNCTIONAL CHECK FLIGHT AND MAINTENANCE OPERATIONAL CHECKS	I
0-2-1	ALPHABETICAL INDEX-ALPHABETICAL LISTING OF EQUIPMENT TO TECHNICAL PUBLICATIONS NO. GROUPS	IN	1-1-312	USE OF HIGH PRESSURE AIR AND NITROGEN - ALL AIRCRAFT	I
0-4-2	CROSS-REFERENCE OF TIME COMPLIANCE TECHNICAL ORDERS AND OVERHAUL CHANGE NUMBERS TO APPLICABLE DATA CODE NUMBERS	IN	1-1-638	EXPEDITIOUS REPAIR AND DISPOSAL OF AEROSPACE VEHICLES	I
<b>GENERAL TECHNICAL ORDERS</b> (00- CATEGORY)			1-1-641	MINIMUM EQUIPMENT REQUIREMENTS FOR OVERWATER, ARCTIC, AND DESERT-TROPIC FLIGHTS	M
00-5-SERIES	TECHNICAL ORDER SYSTEMS - GENERAL	I	1-1-655	RESTRICTED USE OF HIGH POTENTIAL VOLTAGE TESTING APPARATUS ON AIRCRAFT CONTAINING FUEL	I
00-20-SERIES	MAINTENANCE MANAGEMENT SYSTEM - GENERAL	I	<b>GENERAL ENGINEERING MANUALS</b>		
00-25-SERIES	MISCELLANEOUS TECHNICAL ORDERS - GENERAL	I	1-1A-1	ENGINEERING HANDBOOK SERIES FOR AIRCRAFT REPAIR - GENERAL MANUAL FOR STRUCTURAL REPAIR	M
00-25-06-SERIES	WORK UNIT CODE MANUAL	I	1-1A-8	ENGINEERING MANUALS SERIES- AIRCRAFT AND MISSILE-STRUCTURAL HARDWARE	M
00-36-SERIES	ADMINISTRATIVE TECHNICAL ORDERS - GENERAL	I	1-1A-9	ENGINEERING SERIES FOR AIRCRAFT REPAIR AEROSPACE METALS-GENERAL DATA AND USAGE FACTORS	M
00-60-SERIES	ARCTIC, DESERT AND TROPIC TECHNICAL ORDERS (AERONAUTICAL AND GROUND EQUIPMENT) - GENERAL	I	1-1A-11	ENGINEERING MANUAL SERIES FOR ACFT REPAIR - FABRIC REPAIR AND DOPING	I
00-85-SERIES	PROTECTIVE PACKING AND PRESERVATION PACKAGING - GENERAL	I	1-1A-12	ENGINEERING MANUAL SERIES FOR AIRCRAFT REPAIR - FABRICATION, MAINTENANCE AND REPAIR OF TRANSPARENT PLASTICS	M
00-110-SERIES	SPECIAL WEAPONS DEFENSE AND NUCLEAR APPLICATIONS, MONITORING, HANDLING, DISPOSAL AND DECONTAMINATION - GENERAL	I	1-1A-14	INSTALLATION PRACTICES FOR AIRCRAFT ELECTRIC AND ELECTRONIC WIRING	I
<b>AIRCRAFT PUBLICATIONS</b> (1- CATEGORY)			<b>WEIGHT AND BALANCE</b>		
<b>GENERAL AIRCRAFT</b>			1-1B-40	WEIGHT AND BALANCE DATA	M
1-1	TCTO SERIES	I	<b>AIR REFUELING</b>		
1-1-1	CLEANING OF AEROSPACE EQUIPMENT	I	1-1C-1	FLIGHT MANUAL-BASIC FLIGHT CREW AIR REFUELING PROCEDURES	M
1-1-2	CORROSION PREVENTION AND CONTROL FOR AEROSPACE EQUIPMENT	I	1-1C-1-3	FLIGHT MANUAL-FLIGHT CREW AIR REFUELING PROCEDURES-B-52	M
1-1-3	PREPARATION, INSPECTION AND REPAIR OF AIRCRAFT FUEL, OIL AND WATER ALCOHOL CELLS AND INTEGRAL TANKS	M	1-1C-1-5	FLIGHT MANUAL-FLIGHT CREW AIR REFUELING PROCEDURES-B-52B, F (WITH KC-135)	M
1-1-4	EXTERIOR FINISHES, INSIGNIA AND MARKINGS APPLICABLE TO USAF AIRCRAFT	M	1-1C-1-15	FLIGHT MANUAL - FLIGHT CREW AIR REFUELING PROCEDURES-B-52G, H (WITH KC-135 SERIES)	M
1-1-5	ABRASIVE BLASTING METHOD CLEANING AND CORROSION REMOVAL	I	<b>BOMBER AIRCRAFT</b>		
1-1-6	DISPOSITION OF EQUIPMENT SUBMERGED IN WATER	I	1B-52-8	LOCATION AND APPLICATION- EXTERIOR STENCILS-B-52A, B, C, D, E, F, G, H	M
1-1-7	UTILIZATION OF CARTRIDGE PNEUMATIC STARTERS - ALL AIRCRAFT USING APPLICABLE EQUIPMENT	M	1B-52-38	ORG. INT. DEP MAINT INSTRUCTIONS AC STRUCTURAL INTEGRITY	M
1-1-8	APPLICATION AND REMOVAL OF ORGANIC COATINGS, AEROSPACE AND NON-AEROSPACE EQUIPMENT	M	1B-52-101	IMPLEMENTATION OF B-52 AIRCRAFT USAGE REPORT	I
1-1-17	STORAGE OF AIRCRAFT AND MISSILE SYSTEMS	M	1B-52A-01	LIST OF APPLICABLE PUBLICATIONS - USAF SERIES, B-52 AIRCRAFT AND EQUIPMENT	M
1-1-19	INSPECTION, TEST AND REPLACEMENT OF VIBRATION ISOLATORS ON EQUIPMENT IN AIRCRAFT	M	1B-52A-17	STORAGE OF AIRCRAFT B-52-AIRCRAFT	M
1-1-24	MAINTENANCE, REPAIR AND ELECTRICAL REQUIREMENTS FOR FIBERGLASS AIRBORNE RADOMES	I	1B-52B-06	AIRCRAFT MAINTENANCE-WORK UNIT CODE MANUAL-B-52B THRU H	M
1-1-24-1	MAINTENANCE, REPAIR AND ELECTRICAL RMTS. FOR FIBERGLASS AIRBORNE RADOMES (CONF) (TITLE UNCLASS) - B52, F108	I	1B-52B-1-2	FLIGHT MANUAL - PERFORMANCE DATA B-52B, B-52C, B-52D, B-52E AIRCRAFT	M
			1B-52B-1-5	GUNNERS IN-FLIGHT OPERATION INSTRUCTIONS-MD-8 FCS-B-52B THRU F	M

1-1

FIGURE 3. Example chapter 1 pages - Continued.

MIL-L-8031E (USAF)

TO 1B-52G-01

### CHAPTER 1 TECHNICAL MANUALS

TO NUMBER	TITLE	TYPE	TO NUMBER	TITLE	TYPE
	<b>FIRE CONTROL SYSTEMS AND EQUIPMENT - CONTINUED</b>		11F68-22-3	OVERHAUL INSTRUCTIONS WITH PARTS BREAKDOWN SOLENOID VALVE, PART NO. 1371-59942-, ES2182-01, -01A01 (PARKER AIRCRAFT) B-52H	M
11F8-3-7-2	FIELD MAINTENANCE INSTRUCTIONS-AMMUNITION BOX ASSEMBLY, PART NO. 581540-303, -306 (EMERSON) - B-52H	M	11F68-23-3	OVERHAUL INSTRUCTIONS WITH PARTS BREAKDOWN SOLENOID ACTUATED POPPET SHUTOFF VALVE, PART NO. 144825 (WHITTAKER CONTROLS) - B-52	M
11F8-3-7-3	OVERHAUL INSTRUCTIONS-(SAME AS TO 11F8-3-7-2)	M	11F68-23-13	OVERHAUL INSTRUCTIONS WITH PARTS BREAKDOWN -SOLENOID ACTUATED SLEEVE SELECTOR VALVE, PART NO. 1449325 (WHITTAKER CONTROLS) - B-52	M
11F8-3-7-4	ILLUSTRATED PARTS BREAKDOWN-(SAME AS TO 11F8-3-7-2)	M	11F72-2-3-3	OVERHAUL INSTRUCTIONS WITH PARTS BREAKDOWN EJECTION DOOR ACTUATING MECHANISM, PART NO. 596790-1 (EMERSON) - B-52H	M
11F8-4-14-3	OVERHAUL INSTRUCTIONS-JUNCTION BOXES, PART NO. 7705047G1 AND 775048G1 (GENERAL ELECTRIC)	M	11F74-2-2-3	OVERHAUL INSTRUCTIONS-CONTROL HANDLE, PART NO. 2-0004-056 (ARMA-BOSCH) - B-52G	M
11F8-4-14-4	ILLUSTRATED PARTS BREAKDOWN-(SAME AS TO 11F8-4-14-3)	M	11F74-2-2-4	ILLUSTRATED PARTS BREAKDOWN-(SAME AS TO 11F74-2-2-3)	M
11F60-2-2-4	ILLUSTRATED PARTS BREAKDOWN-LINE OF SIGHT POINTER, PART NO. 98012 (AMERICAN BOSCH ARMA CORP)	M	11F88-2-13	OVERHAUL INSTRUCTIONS WITH PARTS BREAKDOWN MANIFOLD ASSEMBLY, PART NO. 2-00025-112 (ARMA)	M
11F61-2-2-13	OVERHAUL INSTRUCTIONS-CONTROL COLUMN, PART NO. 737678, 737680 (AMERICAN BOSCH)	M	11F90-4-3	OVERHAUL INSTRUCTIONS-SPEED DECREASER GEAR ASSEMBLY, PART NO. 581728-301 (EMERSON) - B-52-H	M
11F61-2-2-14	ILLUSTRATED PARTS BREAKDOWN-(SAME AS TO 11F61-2-2-13)	M	11F90-4-4	ILLUSTRATED PARTS BREAKDOWN-(SAME AS TO 11F90-4-3)	M
11F68-4-3	OVERHAUL INSTRUCTIONS-AIR PRESSURE REGULATOR, PART NO. 101100-2, -2A, -2B, -8 (WALLACE O. LEONARD)	M	11F92-2-3	OVERHAUL INSTRUCTIONS WITH PARTS BREAKDOWN PART NO. 890442, PRESSURE REDUCER AND AIR BOTTLE (KIDDE)	M
11F68-4-4	ILLUSTRATED PARTS BREAKDOWN-(SAME AS TO 11F68-4-3)	M		<b>HAZARD DETECTING EQUIPMENT</b>	
11F68-5-3	OVERHAUL INSTRUCTIONS WITH PARTS BREAKDOWN-REVERSE FLOW CHECK VALVE, PART NO. 155000-2 (WALLACE O. LEONARD)	M	11H5-10-1	OPERATION AND SERVICE INSTRUCTIONS-COMBUSTIBLE GAS ALARM, PORTABLE, MODELS 05CGA, 06CGA, 07CGA, 08CGA, STATIONARY, WALL MOUNTED, MODELS 05GAW, 07CGAW, 08CGAW (ERDCO ENGINEERING) - B-52	M
11F68-15-3	OVERHAUL INSTRUCTIONS-SOLENOID VALVE, PART NO. ES2181-01, -01A01, -01A03, PC-449F, -4491 (CADILLAC GAGE) - B-52H	M	11H5-10-4	ILLUSTRATED PARTS BREAKDOWN-PORTABLE COMBUSTIBLE GAS ALARM MODEL 07CGA AND STATIONARY WALL MOUNTED COMBUSTIBLE GAS ALARM MODEL 07CGAW - B-52	M
11F68-15-4	ILLUSTRATED PARTS BREAKDOWN-(SAME AS TO 11F68-15-3)	M		<b>LAUNCHERS AND EQUIPMENT</b>	
11F68-16-3	OVERHAUL INSTRUCTIONS WITH PARTS BREAKDOWN-HYDRAULIC LIMIT VALVE, PART NO. 135359887D, ES2187-01, 01A01, 144925 (WHITTAKER CONTROLS) - B-52H	M	11L1-2-21-1	OPERATION AND MAINTENANCE INSTRUCTIONS - SRAM LAUNCHER P/N 675-12361-602 AND 675-12361-605 (BOEING MAC) - B-52G/H	M
11F68-17-3	OVERHAUL INSTRUCTIONS WITH PARTS BREAKDOWN-SOLENOID VALVE, PART NO. 144935 ES2186-01, -01A01 (WHITTAKER CONTROLS) - B-52H	M	11L1-2-21-6	ILLUSTRATED PARTS BREAKDOWN - (SAME AS TO 11L1-2-21-1)	M
11F68-18-3	OVERHAUL INSTRUCTIONS WITH PARTS ES2187-01, 01A01, 144925 (WHITTAKER CONTROLS) BREAKDOWN-SOLENOID VALVE, PART NO.	M	11L1-4-2-2	FIELD MAINTENANCE INSTRUCTIONS - COUNTERMEASURES EQUIPMENT DISPENSING SET, TYPE ANVALE-25 (BOEING) - B-52H	M
11F68-19-3	OVERHAUL INSTRUCTION-SOLENOID VALVE, PART NO. EA50279-1, ES2191-01, -01A01 01A02 (VICKERS) - B-52H	M	11L1-4-2-4	ILLUSTRATED PARTS BREAKDOWN-(SAME AS TO 11L1-4-2-2)	M
11F68-19-4	ILLUSTRATED PARTS BREAKDOWN-(SAME AS TO 11F68-19-3)	M	11L3-3-6-2	PRELIMINARY-FIELD MAINTENANCE INSTRUCTIONS-CONTROL AND DISPLAY PANELS, AGM-68A, MISSILE-CARRIER EQUIPMENT, PART NO. 2A14402AA-101-11 (BOEING) - B-52	M
11F68-19-13	OVERHAUL INSTRUCTIONS-SOLENOID VALVE, PART NO. H5980048, H5980048M1, H5980048M2, ES2191-01, -01801, -01802, -01803 (PARKER AIRCRAFT) - B-52H	M	11L3-3-6-4	ILLUSTRATED PARTS BREAKDOWN (SAME AS TO 11L3-3-6-2)	M
11F68-19-14	ILLUSTRATED PARTS BREAKDOWN-SOLENOID PART NO. H5980048, ES2191-01801, H5980048M1, ES2191-01802, H5980048M2, ES2191-01803 (PARKER AIRCRAFT) - B-52H AIRCRAFT	M	11N-H5052-2	OPERATION AND MAINTENANCE INSTRUCTIONS MUNITIONS LIFT TRAILER MHU-173/E (AAI CORP) - B-52G	M
11F68-20-3	OVERHAUL INSTRUCTIONS WITH PARTS BREAKDOWN TEMPERATURE SENSITIVE DIRECTIONAL CONTROL VALVE, PART NO. 145195-1, ES2231-01, -01A01 (WHITTAKER CONTROLS) - B-52H AIRCRAFT	M			

1-49

FIGURE 3. Example chapter 1 pages - Continued.

## MIL-L-8031E (USAF)

TO 1B-52G-01

CHAPTER 1  
TECHNICAL MANUALS

TO NUMBER	TITLE	TYPE	TO NUMBER	TITLE	TYPE
	LAUNCHERS AND EQUIPMENT (CONTINUED)		11W1-3-10-3	OVERHAUL INSTRUCTIONS WITH PARTS BREAKDOWN AMMUNITION BOOSTER ROTARY ACTUATOR, MODEL M-7550, M-7550M1 AND M-7550 M2 PART NO. 62-00020-000M-7550M2 (ELECTRONIC COMMUNICATIONS) - B-52	M
11N-H5052-4	ILLUSTRATED PARTS BREAKDOWN (SAME AS TO 11N-H5052-2)	M	11W1-7-9-2	FIELD MAINTENANCE INSTRUCTIONS TYPE M1 M2, M3, M2A1, M3A1 GUN FEEDER FOR 20MM AUTOMATIC GUN M61 - B-52	M
11N-H5053-2	OPERATION AND MAINTENANCE INSTRUCTIONS, GUIDED MISSILE LIFT TRUCK TYPE MHU-174/E PART NUMBER 6CIE10 (STANDARD MANUFACTUR- ING CO.) B-52G	M	11W1-7-9-4	ILLUSTRATED PARTS BREAKDOWN-(SAME AS TO 11W1-7-9-2)	M
11N-H5053-4	ILLUSTRATED PARTS BREAKDOWN (SAME AS TO 11N-H5053-2)	M	11W1-12-4-34	ILLUSTRATED PARTS BREAKDOWN-20 MM AUTOMATIC GUN, TYPE M61, M61A1 (GENERAL ELECTRIC)	M
11N-T5088-2	INTERMEDIATE MAINTENANCE INSTRUCTIONS, WEAPONS CONTROL PANEL C-10722/ASQ-175, PN 675-11485-603	M	11W1-13-3-122	FIELD MAINTENANCE INSTRUCTIONS-CALIBER .50 BASIC AIRCRAFT MACHINE GUN AN-M3	M
11N-T5088-4	ILLUSTRATED PARTS BREAKDOWN-PANEL WEAPON CONTROL C-10722/ASQ-175 PART NUM- BER 675-11485-601 (BOEING) B-52G/H	M	11W1-13-3-124	ILLUSTRATED PARTS BREAKDOWN-(SAME AS TO 11W1-13-3-122)	M
11N-T5089-2	INTERMEDIATE MAINTENANCE INSTRUCTIONS, CONTROL INDICATOR (MCP) C-7861/ASA-73, PN 675-12284-501	M	11W1-21-7-3	OVERHAUL INSTRUCTIONS-PNEUMATIC VALVE, TYPE C-2 (KIDDE) - B-52D	M
11N-T5089-4	ILLUSTRATED PARTS BREAKDOWN-CONTROL- INDICATOR C-7861/ASA-73 PART NUMBER 675- 12284-1 (BOEING) B-52G/H	M	11W1-21-7-4	ILLUSTRATED PARTS BREAKDOWN-(SAME AS TO 11W1-21-7-3)	M
EGRESS SYSTEMS, EXPLOSIVE DEVICES AND EQUIPMENT			11W1-28-3-2	FIELD MAINTENANCE INSTRUCTIONS-M7 ELECTRIC DRIVE AND M12 HYDRAULIC DRIVE FOR 20MM AUTOMATIC GUN M61	M
11P1-14-3	OVERHAUL INSTRUCTIONS WITH ILLUSTRATED PARTS BREAKDOWN -CATAPULT ACFT EJECTION SEAT, M3A1	M	11W1-28-3-4	ILLUSTRATED PARTS BREAKDOWN-(SAME AS TO 11W1-28-3-2)	M
11P1-14-7	STORAGE AND MAINTENANCE PROCEDURES- CATAPULTS, TYPE M3A1, M4A1, M5A1, PART NO. 8503635, 8503668, 8503686	M	AIRBORNE ELECTRONIC EQUIPMENT PUBLICATIONS (12- CATEGORY)		
11P3-1-7	STORAGE AND MAINTENANCE PROCEDURES- CARTRIDGE ACTUATED INITIATORS, MODEL M3A2, M5A2, M6A1, M27, M30A1, M31, M32A1, M45A1, M48A1, M53, M72, M87, M88, M89, M99, M-104, M- 111, M-113, M-114, JAU-2/A25, JAU-3/A25, JAU-4/A25, JAU-8/A25, JAU-9/A25, JAU-10/A25, MX11 SERIES AND 21300000 SERIES	M	RADAR ELECTRONIC EQUIPMENT		
11P3-2-4-3	OVERHAUL INSTRUCTIONS WITH ILLUSTRATED PARTS BREAKDOWN-INITIATORS, TYPES M5A2, M6A1, M28, M31, M72	M	12P3-1-1	CARRIER TAPE SPLICING PROCEDURE AND LOADING INSTRUCTIONS-AIRCRAFT CHAFF DIS- PENSING SYSTEM USING RR-(A)U AND RR-(J) AL TYPES CHAFF	I
11P3-2-5-3	OVERHAUL INSTRUCTIONS WITH ILLUSTRATED PARTS BREAKDOWN-INITIATOR (CARTRIDGE AC- TUATED) MODELS M30A1, M32A1, M45A1, M48A1	M	12P3-2ALE1-42	FIELD MAINTENANCE INSTRUCTIONS- COUNTERMEASURES CHAFF DISPENSING SET, MODEL ANVALE (WEBSTER-CHICAGO)	M
11P4-1-7	STORAGE PROCEDURES-AIRCRAFT CANOPY REMOVERS M13A, M2A1, RAU-1A, M4, M8A1, M9 AND PART NO. 2218 SERIES	M	12P3-2ALE20-2	FIELD MAINTENANCE INSTRUCTIONS-FLARE EJECTOR SET, TYPE ANVALE-20(V) (DYNALECTRON) - B-52G	M
11P6-1-7	STORAGE AND MAINTENANCE PROCEDURES- CARTRIDGE ACTUATED THRUSTERS, MODELS M1A2, M2A1, M2A2, M3A3, M5A2, M7, M8, M11, M13, M15, M18, M17, M18, M19, M20A1, M25, M25A1, M26 PART NO. 807288 AND 30247-3	M	12P3-2ALE20-4	ILLUSTRATED PARTS BREAKDOWN-FLARE EJECTION SYSTEM, TYPE ANVALE-20 (DYNALECTRON) - B- 52G	M
11P8-1-17	STORAGE AND MAINTENANCE PROCEDURES- EXPLOSIVE ROTARY ACTUATOR ASSEMBLY, PART NO. 1000 SERIES	M	12P3-2ALE24-2	FIELD MAINTENANCE INSTRUCTIONS- COUNTERMEASURE EQUIPMENT DISPENSING SET, TYPE ANVALE-24 (RYAN) - B-52H	M
11P8-7-3	OVERHAUL INSTRUCTIONS WITH ILLUSTRATED PARTS BREAKDOWN-ROTARY ACTUATOR, SERIES 1000	M	12P3-2ALE24-3	OVERHAUL INSTRUCTIONS-(SAME AS 12P3-2ALE24-3)	M
WEAPONS AND EQUIPMENT			12P3-2ALE24-4	ILLUSTRATED PARTS BREAKDOWN - (SAME AS 12P3-2ALE24-2)	M
11W1-3-6-3	OVERHAUL INSTRUCTIONS-ELECTRONIC AMMUNITION BOOSTERS, PART NO. 29492-1, -2, 20510-1, -2, 30582-1, -2, 30802-2, -4 (AIRESEARCH)	M	12P3-ALQ117-2	CONFIDENTIAL - INTERMEDIATE MAINTENANCE INSTRUCTIONS - COUNTERMEASURES SET, TYPE ANALO-117 (U), PN 2612800G004 (ITT) (TITLE UNCL)	M
			12P3-2ALQ117-3	CONFIDENTIAL - OVERHAUL INSTRUCTIONS - (SAME AS TO 12P3-2-2ALQ117-2)	M
			12P3-2ALQ117-4	ILLUSTRATED PARTS BREAKDOWN - (SAME AS 12P3-2ALQ117-2)	M

1-50

FIGURE 3. Example chapter 1 pages - Continued.

MIL-L-8031E (USAF)

TO 1E-3A-01

## CHAPTER 2

### EQUIPMENT PART NUMBER TO TECHNICAL MANUAL NUMBER

PART NUMBER	TO NUMBER	PART NUMBER	TO NUMBER
A-1	33AA7-6-21 33AA7-6-24	AFM27M-1	35AA2-3-5-1 35AA2-3-5-3 35AA2-3-5-4 35AA2-3-5-11 35AA2-3-5-13 35AA2-3-5-14 35A2-4-6-11 35A2-4-6-13 35A2-4-6-14
A/A37D-1	1E-3A-18	AFM32R-3	35D3-6-27-11
A/E7T-25	33AA17-138-1 33AA17-138-4	AF37A-T4-5	35C1-4-1-102
A/E24U-10	35C3-2-57-1 35C3-2-57-4	AHT-55	33A2-2-31-1 33A2-2-31-3 33A2-2-31-4
A/E37T-25	33AA17-138-1 33AA17-138-4	AHT-56	33A2-2-31-11 33A2-2-31-13 33A2-2-31-14
A/F37A-T72	43D3-10-2-1-1 THRU 43D3-10-2-1-7 43D3-10-2-1-8-1 THRU 43D3-10-2-1-8-3 43D3-10-2-1-9-1 THRU 43D3-10-2-1-9-6 43D3-10-2-1-9-8 43D3-10-2-4-1 THRU 43D3-10-2-4-9 43D3-10-2-6 43D3-10-2-43 43D3-10-2-73 43D3-10-2-508 43X5-18-16-3 43X43-19-3 43X56-2-3	AHT-56A	33A2-2-24-21 33A2-2-24-23 33A2-2-24-24
A/M32A-60	35C2-3-372-1 35C2-3-372-3 35C2-3-372-4 35C2-3-372-522 35C2-3-372-526	AHT-56B	33A2-2-27-11 33A2-2-27-13 33A2-2-27-14
A/M32A-60A	35C2-3-372-11 35C2-3-372-14 35C2-3-372-522 35C2-3-372-526	AI-903M	5F8-3-35-2 5F8-3-35-3 5F8-3-35-4
AAU-19/A	5F3-3-15-13 5F3-3-15-14 5F3-3-15-22	ALL-278-001	33A1-7-89-21
AAU-19A/A	5F3-3-15-22 5F3-15-33 5F3-3-15-34	AM-624/ARA-50	51R1-2-3-2 51R1-2-3-18-1
AAU-27/A	5F3-3-19-2 5F3-3-19-3 5F3-3-19-4	AM-6672/A	12R2-2A-223
ABU-8/A	5F2-17-3 5F2-17-4	AM-6808/APY-1	12P2-2APY1-2-1
ABU-11/A	5N11-2-11-33	AN/ALM-5	33D7-4-54-1 33D7-4-54-4
AC-4700	34Y1-87-31 34Y1-87-33 34Y1-87-34	AN/APM-123(V)1,(V)2,(V)3	33A1-3-367-1 33A1-3-367-34
ACE-233-002	35-1-251-1	AN/APM-217	33D7-44-77-1 33D7-44-77-4
ACE-406-322	35E9-168-11 35E9-168-14	AN/APM-238A	33A1-3-358-24
ACE-406-329	35E9-207-1 35E9-207-4	AN/APM-401	33D7-36-35-1 33D7-36-35-1-1 33D7-36-35-4
ACE-410-922	35E10-22-1 35E10-22-4	AN/APM-402	33D7-47-55-1
ADK-182A/A24G-1A	5A2-7-4-3 5A2-7-4-3	AN/APM-411	33D7-49-90-1 33D7-49-90-4 33D7-49-90-11 33D7-49-90-14 33D7-49-90-21 33D7-49-90-24 33D7-49-90-31 33D7-49-90-34 33D7-49-90-41 33D7-49-90-44
ADU-461/E	8-1-103	AN/APM-412	33D7-3-179-1 33D7-3-179-4
ADU-485/E	33AA50-3-1	AN/APM-413	33D7-44-227-1 33D7-44-227-4
ADU-489/E	33AA50-3-1	AN/APN-213	12P5-2APN213-2
AD31450-7	33D2-39-20-1	AN/APS-133	1E-3A-769
		AN/APX-103	33AA1-1-101

2-1

FIGURE 4. Example chapter 2 page.



MIL-L-8031E(USAF)  
APPENDIX A

LIST OF APPLICABLE PUBLICATIONS  
DOCUMENT TYPE DEFINITION (DTD) SUBSET

10. SCOPE.

10.1 Scope. The markup tags described herein are based on rules outlined in the Information Processing, Text and Office Systems, Standard Generalized Markup Language (SGML) Standard, ISO 8879 and MIL-M-28001. The Document Type Definition (DTD) subset within this appendix provides the structure and content of documents prepared in accordance with this specification; the Tag Description table within this appendix provides a detailed discussion of each markup tag. This Appendix is a mandatory part of this specification. The information contained herein is intended for compliance.

20. APPLICABLE DOCUMENTS.

20.1 Government documents.

20.1.1 Specifications, standards, and handbooks. The following specifications, standards and handbooks form a part of this document to the extent specified herein. Unless otherwise specified, the issues of these documents are those listed in the issue of the Department of Defense Index of Specifications and Standards (DODISS) and supplement thereto, cited in the solicitation. (see 6.2)

SPECIFICATIONS

MILITARY

MIL-M-28001	Markup Requirements and Generic Style Specification for Electronic Printed Output and Exchange of Text
-------------	--

20.2 Non-government publications. The following document forms a part of this document to the extent specified herein. Unless otherwise specified, the issues of the documents which are DoD adopted are those listed in the issue of the DODISS cited in the solicitation. Unless otherwise specified, the issues of documents not listed in the DODISS are the issues of the documents cited in the solicitation. (see 6.2)

MIL-L-8031E(USAF)  
APPENDIX A

ISO 8879

Information Processing - Text and Office  
Systems - Standard Generalized Markup  
Language (SGML) Standard

(Application for copies should be addressed to the American  
National Standards Institute, 1430 Broadway, New York, NY 10018.)

**30. DOCUMENT TYPE DEFINITION SUBSET.**

30.1 SGML document type definition subset. Data to be delivered  
digitally in accordance with this specification shall be tagged  
using the DTD found in MIL-M-38784 as modified by the DTD  
subset in this section. The procedure for accomplishing this is  
found in MIL-M-28001.

30.2 Template document type for List of Applicable Publications.  
The DTD subset for the List of Applicable Publications DTD is as  
follows:

<!-- The following set of declarations may be referred to by  
using a public entity as follows:

```
<!ENTITY % m8031e PUBLIC "-//USA-DOD//DTD MIL-L-8031E//EN" >
%m8031e;
-->
```

<!-- NOTE: In order to parse the following DTD subset alone,  
append the following statement to the beginning of the file:

```
<!DOCTYPE docloaps [
```

and the associated `]>` to the end of the file. -->

```
<!-- ENTITY DECLARATIONS -->
```

```
<!ENTITY % m38784c PUBLIC "-//USA-DOD//DTD MIL-M-38784C//EN" >
```

```
<!ENTITY % frnt `(idinfo, lep, verstat?, contents, foreword)` >
```

```
<!ENTITY % bodyele `(chapter1, chapter2)` >
```

```
%m38784c;
```



MIL-L-8031E(USAF)  
APPENDIX A

<!-- ELEMENT and ATTRIBUTE LIST DECLARATIONS -->

```

<!ELEMENT chapter1      - - (%titles;, mainsers+) >
<!ATTLIST chapter1      shortentry %yesorno; '0'
                        %bodyatt;
                        tocentry %yesorno; '1'
                        verified %yesorno; '0'
                        %secur; >

<!ELEMENT chapter2      - - (%titles;, (partno, tmidno+)+) >
<!ATTLIST chapter2      shortentry %yesorno; '0'
                        verified %yesorno; '0'
                        tocentry %yesorno; '1'
                        %bodyatt;
                        %secur; >

<!ELEMENT docloaps      - - (front, body) >
<!ATTLIST docloaps      service %service; 'AF'
                        %docatt;
                        %secur; >

<!ELEMENT mainsers      - - (title, (subsert+ : (tmidno, title,
pubtype)+)) >
<!ATTLIST mainsers      tocentry %yesorno; '1'
                        shortentry %yesorno; '0'
                        verified %yesorno; '0'
                        %bodyatt;
                        %secur; >

<!ELEMENT pubtype       - o (%text;) >
<!ATTLIST pubtype       %secur; >

<!ELEMENT subserts      - - (title, (tmidno, title, pubtype)+) >
<!ATTLIST subserts      %bodyatt;
                        %secur; >

```

#### 40. DETAILED TAG DESCRIPTION

**40.1 Tag Description Table.** The following table provides detailed descriptions of the tags above. It provides the element tagging structure, full element name, tag minimization requirements, element structure, referencing elements, source paragraph, and attribute descriptions.

## MIL-L-8031E (USAF)

## APPENDIX A

**TABLE A-I. Tag Description**

Tag	Description
<b>&lt;body</b> <b>security = x&gt;</b>	<p><b>Body Matter</b></p> <p>Identifies the beginning of the body matter.</p> <p>The body matter element requires a starting tag (&lt;body&gt;) and an ending tag (&lt;/body&gt;).</p> <p>This element contains the following structure:</p> <ul style="list-style-type: none"> <li>one chapter 1 (&lt;chapter1&gt;) element; followed by,</li> <li>one chapter 2 (&lt;chapter2&gt;) element.</li> </ul> <p>The body matter element may also contain (at any point):</p> <ul style="list-style-type: none"> <li>footnote (&lt;ftnote&gt;).</li> </ul> <p>The body matter is part of the document (&lt;docloaps&gt;), the document part (&lt;docpart&gt;), and the volume (&lt;volume&gt;).</p> <p>Source Paragraph: 3.2.2 &amp; 3.2.3 - MIL-L-8031E</p> <p><b><u>Optional Attribute(s):</u></b></p> <p>SECURITY: Specifies the level of security of the element. The value of this attribute may be set to one of the following values: "u" (Unclassified), "c" (Confidential), "s" (Secret). The default value of this attribute is "u".</p>

## MIL-L-8031E (USAF)

## APPENDIX A

TABLE A-I. Tag Description - Continued.

Tag	Description
<b>&lt;chapter1</b> <b>applicrefid = x</b> <b>applictype = x</b> <b>assem = x</b> <b>assocfig = x</b> <b>assoctab = x</b> <b>compon = x</b> <b>contype = x</b> <b>delchlvl = x</b> <b>esds = x</b> <b>hcp = x</b> <b>id = x</b> <b>inschlvl = x</b> <b>label = x</b> <b>lru = x</b> <b>module = x</b> <b>partno = x</b> <b>refdes = x</b> <b>security = x</b> <b>shortentry = x</b> <b>skilltrk = x</b> <b>sssn = x</b> <b>ssubassm = x</b> <b>subassem = x</b> <b>texttype = x</b> <b>tocentry = x</b> <b>unit = x</b> <b>verified = x&gt;</b>	<p><b>Chapter 1</b></p> <p>Identifies the beginning of chapter one.</p> <p>The chapter 1 element requires a starting tag (&lt;chapter1&gt;) and an ending tag (&lt;/chapter1&gt;).</p> <p>This element contains the following structure:  one title (&lt;title&gt;) element; followed by,  one or more main series headings (&lt;mainsers&gt;) elements.</p> <p>The chapter 1 is part of the body matter (&lt;body&gt;).</p> <p>Source Paragraph: 3.2.2 - MIL-L-8031E</p> <p><b>Optional Attribute(s):</b></p> <p><b>APPLICREFID:</b> References unique identifier(s) assigned to applicability identifier(s) (&lt;applicid id="xxx"&gt;). The value of this attribute consists of a list of references to names previously entered as unique identifiers of other elements. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>APPLICTYPE:</b> This attribute references unique identifier(s) assigned to applicability definitions (&lt;applicdef id="xxx"&gt;). Although it is possible to derive the applicability type from the applicability reference identifier, it may be explicitly stated with this attribute. The value of this attribute consists of a list of references to names previously entered as unique identifiers of other elements. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>ASSEM:</b> Specifies the assembly number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>ASSOCFIG:</b> Identifies a figure associated with the element through the use of the "id" attribute in the figure (&lt;figure&gt;) element. The value of this attribute consists of a list of references to names previously entered as unique identifiers of other elements. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>ASSOCTAB:</b> Identifies a table associated with the element through the use of the "id" attribute in the table (&lt;table&gt;) element. The value of this attribute consists of a list of references to names previously entered as unique identifiers of other elements. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>COMPON:</b> Specifies the component number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p>

MIL-L-8031E (USAF)  
APPENDIX A

**TABLE A-I. Tag Description - Continued.**

Tag	Description
<chapter1> - cont.	<p><b>CONTYPE:</b> Identifies the content type of the element. When used with steps, the implied value is procedural. When used with all other element types, the implied value is descriptive. The value of this attribute may be set to one of the following values: "desc" (Descriptive), "proc" (Procedural). If no value is specified for this attribute, one may be implied by the system.</p> <p><b>DELCHLV:</b> Specifies the change level(s) at which information was deleted. An audit trail can be maintained by listing multiple change levels separated by commas. The value of this attribute consists of a name where the first character is numeric. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>ESDS:</b> Electrostatic Discharge Sensitive parts - If the value is set to zero, the element does not contain information involving ESDS parts, components or circuits. If any other value is given, the element does contain information involving ESDS items. The value of this attribute consists of a number. The default value of this attribute is "0".</p> <p><b>HCP:</b> Hardness Critical Process - If the value is set to zero, there is no hardness critical information. If any other value is given, the element contains hardness critical information. The value of this attribute consists of a number. The default value of this attribute is "0".</p> <p><b>ID:</b> An identifier of the element which is assigned at origination and which remains unchanged as the document is revised or updated even though the automatically assigned enumeration or manually assigned "labels" change. The value of the "id" is used making references to the element from other portions of a document. If no "id" is given, none will be maintained and the element can then not be cross-referenced to by means of an IDREF on another element or with a cross-reference (&lt;xref&gt;). The value of this attribute defines a unique identifier for the element. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>INSCHLV:</b> Specifies the change level(s) at which information was inserted. An audit trail can be maintained by listing multiple change levels separated by commas. The value of this attribute consists of a name where the first character is numeric. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>LABEL:</b> The label associated with the element (i.e. chapter number). This attribute is only appropriate for manually enumerated documents. Typically, the output system will automatically enumerate the elements requiring enumeration, in which case this attribute would be omitted. The value of this attribute consists of a name where the first character is alphanumeric. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>LRU:</b> Specifies the line replaceable unit (LRU) number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p>

## MIL-L-8031E (USAF)

## APPENDIX A

TABLE A-I. Tag Description - Continued.

Tag	Description
<chapter1> - cont.	<p><b>MODULE:</b> Specifies the module number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>PARTNO:</b> Specifies the equipment part number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>REFDES:</b> Specifies the appropriate reference designator associated with the information. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>SECURITY:</b> Specifies the level of security of the element. The value of this attribute may be set to one of the following values: "u" (Unclassified), "c" (Confidential), "s" (Secret). The default value of this attribute is "u".</p> <p><b>SHORTENTRY:</b> Specifies that the shortened title (&lt;shorttitle&gt;) is used for this element. If the value is set to zero, the short title is not used. If any other value is given, the short title will be used. The value of this attribute consists of a number. The default value of this attribute is "0".</p> <p><b>SKILLTRK:</b> Designates the skill level of the user at which the information in this element is aimed. The value of this attribute consists of a list of names where the first character of each name is alphanumeric. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>SSSN:</b> Specifies the system/subsystem/sub-assembly (SSSN) code associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>SSUBASSM:</b> Specifies the sub-subassembly number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>SUBASSEM:</b> Specifies the subassembly number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>TEXTTYPE:</b> Specifies a code which further identifies the element. The value of this attribute consists of a number. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>TOCENTRY:</b> Specifies whether the element will be included in the table of contents for the document. If the value is set to zero, the element will not be included in the table of contents. If any other value is given, the element will be included. The value of this attribute consists of a number. The default value of this attribute is "1".</p>

## MIL-L-8031E (USAF)

## APPENDIX A

TABLE A-I. Tag Description - Continued.

Tag	Description
<b>&lt;chapter1&gt; - cont.</b>	<p><b>UNIT:</b> Specifies the unit number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>VERIFIED:</b> Specifies the verification status of the information. This information is used to build the verification status (&lt;verstat&gt;) page. If the value is set to zero, the information has not been verified. If any other value is given, the information has been verified. The value of this attribute consists of a number. The default value of this attribute is "0".</p>
<b>&lt;chapter2</b> <b>applicrefid = x</b> <b>applictype = x</b> <b>assem = x</b> <b>assocfig = x</b> <b>assoctab = x</b> <b>compon = x</b> <b>contype = x</b> <b>delchlvl = x</b> <b>esds = x</b> <b>hcp = x</b> <b>id = x</b> <b>inschlvl = x</b> <b>label = x</b> <b>lru = x</b> <b>module = x</b> <b>partno = x</b> <b>refdes = x</b> <b>security = x</b> <b>shortentry = x</b> <b>skilltrk = x</b> <b>sssn = x</b> <b>ssubassm = x</b> <b>subassem = x</b> <b>texttype = x</b> <b>tocentry = x</b> <b>unit = x</b> <b>verified = x&gt;</b>	<p><b>Chapter 2</b></p> <p>Identifies the beginning of chapter two.</p> <p>The chapter 2 element requires a starting tag (&lt;chapter2&gt;) and an ending tag (&lt;/chapter2&gt;).</p> <p>This element contains the following structure:</p> <ul style="list-style-type: none"> <li>one title (&lt;title&gt;) element; followed by,</li> <li>a group of elements consisting of: <ul style="list-style-type: none"> <li>one equipment part number (&lt;partno&gt;) element; followed by,</li> <li>one or more technical manual identification number (&lt;tmidno&gt;) elements; which may occur one or more times.</li> </ul> </li> </ul> <p>The chapter 2 is part of the body matter (&lt;body&gt;).</p> <p>Source Paragraph: 3.2.3 - MIL-L-8031E</p> <p><b>Optional Attribute(s):</b></p> <p><b>APPLICREFID:</b> References unique identifier(s) assigned to applicability identifier(s) (&lt;applicid id="xxx"&gt;). The value of this attribute consists of a list of references to names previously entered as unique identifiers of other elements. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>APPLICTYPE:</b> This attribute references unique identifier(s) assigned to applicability definitions (&lt;applicdef id="xxx"&gt;). Although it is possible to derive the applicability type from the applicability reference identifier, it may be explicitly stated with this attribute. The value of this attribute consists of a list of references to names previously entered as unique identifiers of other elements. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>ASSEM:</b> Specifies the assembly number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>ASSOCFIG:</b> Identifies a figure associated with the element through the use of the "id" attribute in the figure (&lt;figure&gt;) element. The value of this attribute consists of a list of references to names previously entered as unique</p>

MIL-L-8031E (USAF)

## APPENDIX A

TABLE A-I. Tag Description - Continued.

Tag	Description
<chapter2> - cont.	<p>identifiers of other elements. If no value is specified for this attribute, one may be implied by the system.</p> <p>ASSOCTAB: Identifies a table associated with the element through the use of the "id" attribute in the table (&lt;table&gt;) element. The value of this attribute consists of a list of references to names previously entered as unique identifiers of other elements. If no value is specified for this attribute, one may be implied by the system.</p> <p>COMPON: Specifies the component number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>CONTYPE: Identifies the content type of the element. When used with steps, the implied value is procedural. When used with all other element types, the implied value is descriptive. The value of this attribute may be set to one of the following values: "desc" (Descriptive), "proc" (Procedural). If no value is specified for this attribute, one may be implied by the system.</p> <p>DELCHLVL: Specifies the change level(s) at which information was deleted. An audit trail can be maintained by listing multiple change levels separated by commas. The value of this attribute consists of a name where the first character is numeric. If no value is specified for this attribute, one may be implied by the system.</p> <p>ESDS: Electrostatic Discharge Sensitive parts - If the value is set to zero, the element does not contain information involving ESDS parts, components or circuits. If any other value is given, the element does contain information involving ESDS items. The value of this attribute consists of a number. The default value of this attribute is "0".</p> <p>HCP: Hardness Critical Process - If the value is set to zero, there is no hardness critical information. If any other value is given, the element contains hardness critical information. The value of this attribute consists of a number. The default value of this attribute is "0".</p> <p>ID: An identifier of the element which is assigned at origination and which remains unchanged as the document is revised or updated even though the automatically assigned enumeration or manually assigned "labels" change. The value of the "id" is used making references to the element from other portions of a document. If no "id" is given, none will be maintained and the element can then not be cross-referenced to by means of an IDREF on another element or with a cross-reference (&lt;xref&gt;). The value of this attribute defines a unique identifier for the element. If no value is specified for this attribute, one may be implied by the system.</p> <p>INSCHLVL: Specifies the change level(s) at which information was inserted. An audit trail can be maintained by listing multiple change levels separated by commas. The value of this attribute consists of a name where the first</p>



MIL-L-8031E (USAF)  
APPENDIX A

**TABLE A-I. Tag Description - Continued.**

Tag	Description
<b>&lt;chapter2&gt; - cont.</b>	<p>character is numeric. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>LABEL:</b> The label associated with the element (i.e. chapter number). This attribute is only appropriate for manually enumerated documents. Typically, the output system will automatically enumerate the elements requiring enumeration, in which case this attribute would be omitted. The value of this attribute consists of a name where the first character is alphanumeric. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>LRU:</b> Specifies the line replaceable unit (LRU) number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>MODULE:</b> Specifies the module number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>PARTNO:</b> Specifies the equipment part number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>REFDES:</b> Specifies the appropriate reference designator associated with the information. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>SECURITY:</b> Specifies the level of security of the element. The value of this attribute may be set to one of the following values: "u" (Unclassified), "c" (Confidential), "s" (Secret). The default value of this attribute is "u".</p> <p><b>SHORTENTRY:</b> Specifies that the shortened title (&lt;shorttitle&gt;) is used for this element. If the value is set to zero, the short title is not used. If any other value is given, the short title will be used. The value of this attribute consists of a number. The default value of this attribute is "0".</p> <p><b>SKILLTRK:</b> Designates the skill level of the user at which the information in this element is aimed. The value of this attribute consists of a list of names where the first character of each name is alphanumeric. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>SSSN:</b> Specifies the system/subsystem/sub-assembly (SSSN) code associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>SSUBASSM:</b> Specifies the sub-subassembly number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p>



MIL-L-8031E (USAF)  
APPENDIX A

**TABLE A-I. Tag Description - Continued.**

Tag	Description
<b>&lt;chapter2&gt; - cont.</b>	<p><b>SUBASSEM:</b> Specifies the subassembly number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>TEXTTYPE:</b> Specifies a code which further identifies the element. The value of this attribute consists of a number. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>TOCENTRY:</b> Specifies whether the element will be included in the table of contents for the document. If the value is set to zero, the element will not be included in the table of contents. If any other value is given, the element will be included. The value of this attribute consists of a number. The default value of this attribute is "1".</p> <p><b>UNIT:</b> Specifies the unit number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>VERIFIED:</b> Specifies the verification status of the information. This information is used to build the verification status (&lt;verstat&gt;) page. If the value is set to zero, the information has not been verified. If any other value is given, the information has been verified. The value of this attribute consists of a number. The default value of this attribute is "0".</p>
<b>&lt;docloaps</b> <b>docid = x</b> <b>docstat = x</b> <b>mantype = x</b> <b>security = x</b> <b>service = x&gt;</b>	<p><b>Document</b></p> <p>Identifies the beginning of the technical document.</p> <p>The document element requires a starting tag (&lt;docloaps&gt;) and an ending tag (&lt;/docloaps&gt;).</p> <p>This element contains the following structure:</p> <ul style="list-style-type: none"> <li>one front matter (&lt;front&gt;) element; followed by,</li> <li>one body matter (&lt;body&gt;) element.</li> </ul> <p>The document is not part of any other element.</p> <p>Source Paragraph: 3.2 - MIL-L-8031E</p> <p><b>Required Attribute(s):</b></p> <p><b>DOCID:</b> Unique identifier of the document, which can be used to perform interdocument cross references. However, it should be noted that this is a particular of the application and is not an SGML construct that is validated by the parser. The value of this attribute consists of character data.</p> <p><b>Optional Attribute(s):</b></p> <p><b>DOCSTAT:</b> Specifies the current status of the document specification. The value of this attribute may be set to one of the following values: "revision", "change", "prelim", "draft", "formal". The default value of this attribute is "prelim".</p>

## MIL-L-8031E (USAF)

## APPENDIX A

TABLE A-I. Tag Description - Continued.

Tag	Description
<b>&lt;docloaps&gt; - cont.</b>	<p><b>MANTYPE:</b> Designates the manual type of the document publication. The value of this attribute may be set to one of the following values: "standard", "card", "decal". The default value of this attribute is "standard".</p> <p><b>SECURITY:</b> Specifies the level of security of the element. The value of this attribute may be set to one of the following values: "u" (Unclassified), "c" (Confidential), "s" (Secret). The default value of this attribute is "u".</p> <p><b>SERVICE:</b> Identifies the service primarily responsible for the document. The value of this attribute may be set to one of the following values: "AF" (Air Force), "NAVY", "ARMY", "MC" (Marine Corps), "DLA" (Defense Logistics Agency), "CG" (Coast Guard). The default value of this attribute is "AF".</p>
<b>&lt;front security = x&gt;</b>	<p><b>Front Matter</b></p> <p>Identifies the beginning of the front matter.</p> <p>The front matter element requires a starting tag (&lt;front&gt;) and an ending tag (&lt;/front&gt;).</p> <p>This element contains the following structure:</p> <ul style="list-style-type: none"> <li>one identification information (&lt;idinfo&gt;) element; followed by,</li> <li>one list of effective pages (&lt;lep&gt;) element; followed by,</li> <li>an optional verification status pages (&lt;verstat&gt;) element; followed by,</li> <li>one table of contents (&lt;contents&gt;) element; followed by,</li> <li>one foreword (&lt;foreword&gt;) element.</li> </ul> <p>The front matter is part of the document (&lt;docloaps&gt;), the document part (&lt;docpart&gt;), and the volume (&lt;volume&gt;).</p> <p>Source Paragraph: 3.2.1 - MIL-L-8031E</p> <p><b>Optional Attribute(s):</b></p> <p><b>SECURITY:</b> Specifies the level of security of the element. The value of this attribute may be set to one of the following values: "u" (Unclassified), "c" (Confidential), "s" (Secret). The default value of this attribute is "u".</p>

## MIL-L-8031E (USAF)

## APPENDIX A

TABLE A-I. Tag Description - Continued.

Tag	Description
<b>&lt;mainseries&gt;</b> <b>applicrefid = x</b> <b>applictype = x</b> <b>assem = x</b> <b>assocfig = x</b> <b>assoctab = x</b> <b>compon = x</b> <b>contype = x</b> <b>delchlvl = x</b> <b>esds = x</b> <b>hcp = x</b> <b>id = x</b> <b>inschlvl = x</b> <b>label = x</b> <b>lru = x</b> <b>module = x</b> <b>partno = x</b> <b>refdes = x</b> <b>security = x</b> <b>shortentry = x</b> <b>skilltrk = x</b> <b>sssn = x</b> <b>ssubassm = x</b> <b>subassem = x</b> <b>texttype = x</b> <b>tocentry = x</b> <b>unit = x</b> <b>verified = x&gt;</b>	<p><b>Main Series Headings</b></p> <p>Identifies the beginning of the main series headings.</p> <p>The main series headings element requires a starting tag (&lt;mainseries&gt;) and an ending tag (&lt;/mainseries&gt;).</p> <p>This element contains the following structure:</p> <ul style="list-style-type: none"> <li>one title (&lt;title&gt;) element; followed by,</li> <li>a group of elements consisting of: <ul style="list-style-type: none"> <li>one or more subseries headings (&lt;subseries&gt;) elements; or,</li> <li>a group of elements consisting of: <ul style="list-style-type: none"> <li>one technical manual identification number (&lt;tmidno&gt;) element;</li> </ul> </li> </ul> </li> <li>followed by, <ul style="list-style-type: none"> <li>one title (&lt;title&gt;) element; followed by,</li> <li>one publication type (&lt;pubtype&gt;) element;</li> </ul> </li> <li>which may occur one or more times;</li> <li>which may occur once.</li> </ul> <p>The main series headings is part of the chapter 1 (&lt;chapter1&gt;).</p> <p>Source Paragraph: 3.2.2.1 - MIL-L-8031E</p> <p><b>Optional Attribute(s):</b></p> <p><b>APPLICREFID:</b> References unique identifier(s) assigned to applicability identifier(s) (&lt;applicid id="xxx"&gt;). The value of this attribute consists of a list of references to names previously entered as unique identifiers of other elements. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>APPLICTYPE:</b> This attribute references unique identifier(s) assigned to applicability definitions (&lt;applicdef id="xxx"&gt;). Although it is possible to derive the applicability type from the applicability reference identifier, it may be explicitly stated with this attribute. The value of this attribute consists of a list of references to names previously entered as unique identifiers of other elements. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>ASSEM:</b> Specifies the assembly number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>ASSOCFIG:</b> Identifies a figure associated with the element through the use of the "id" attribute in the figure (&lt;figure&gt;) element. The value of this attribute consists of a list of references to names previously entered as unique identifiers of other elements. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>ASSOCTAB:</b> Identifies a table associated with the element through the use of the "id" attribute in the table (&lt;table&gt;) element. The value of this attribute</p>

## MIL-L-8031E (USAF)

## APPENDIX A

**TABLE A-I. Tag Description - Continued.**

Tag	Description
<b>&lt;mainisers&gt; - cont.</b>	<p>consists of a list of references to names previously entered as unique identifiers of other elements. If no value is specified for this attribute, one may be implied by the system.</p> <p>COMPON: Specifies the component number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>CONTYPE: Identifies the content type of the element. When used with steps, the implied value is procedural. When used with all other element types, the implied value is descriptive. The value of this attribute may be set to one of the following values: "desc" (Descriptive), "proc" (Procedural). If no value is specified for this attribute, one may be implied by the system.</p> <p>DELCHLVL: Specifies the change level(s) at which information was deleted. An audit trail can be maintained by listing multiple change levels separated by commas. The value of this attribute consists of a name where the first character is numeric. If no value is specified for this attribute, one may be implied by the system.</p> <p>ESDS: Electrostatic Discharge Sensitive parts - If the value is set to zero, the element does not contain information involving ESDS parts, components or circuits. If any other value is given, the element does contain information involving ESDS items. The value of this attribute consists of a number. The default value of this attribute is "0".</p> <p>HCP: Hardness Critical Process - If the value is set to zero, there is no hardness critical information. If any other value is given, the element contains hardness critical information. The value of this attribute consists of a number. The default value of this attribute is "0".</p> <p>ID: An identifier of the element which is assigned at origination and which remains unchanged as the document is revised or updated even though the automatically assigned enumeration or manually assigned "labels" change. The value of the "id" is used making references to the element from other portions of a document. If no "id" is given, none will be maintained and the element can then not be cross-referenced to by means of an IDREF on another element or with a cross-reference (&lt;xref&gt;). The value of this attribute defines a unique identifier for the element. If no value is specified for this attribute, one may be implied by the system.</p> <p>INSCHLVL: Specifies the change level(s) at which information was inserted. An audit trail can be maintained by listing multiple change levels separated by commas. The value of this attribute consists of a name where the first character is numeric. If no value is specified for this attribute, one may be implied by the system.</p> <p>LABEL: The label associated with the element (i.e. chapter number). This attribute is only appropriate for manually enumerated documents. Typically,</p>

MIL-L-8031E (USAF)  
APPENDIX A

**TABLE A-I. Tag Description - Continued.**

Tag	Description
<mainisers> - cont.	<p>the output system will automatically enumerate the elements requiring enumeration, in which case this attribute would be omitted. The value of this attribute consists of a name where the first character is alphanumeric. If no value is specified for this attribute, one may be implied by the system.</p> <p>LRU: Specifies the line replaceable unit (LRU) number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>MODULE: Specifies the module number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>PARTNO: Specifies the equipment part number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>REFDES: Specifies the appropriate reference designator associated with the information. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>SECURITY: Specifies the level of security of the element. The value of this attribute may be set to one of the following values: "u" (Unclassified), "c" (Confidential), "s" (Secret). The default value of this attribute is "u".</p> <p>SHORTENTRY: Specifies that the shortened title (&lt;shorttitle&gt;) is used for this element. If the value is set to zero, the short title is not used. If any other value is given, the short title will be used. The value of this attribute consists of a number. The default value of this attribute is "0".</p> <p>SKILLTRK: Designates the skill level of the user at which the information in this element is aimed. The value of this attribute consists of a list of names where the first character of each name is alphanumeric. If no value is specified for this attribute, one may be implied by the system.</p> <p>SSSN: Specifies the system/subsystem/sub-assembly (SSSN) code associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>SSUBASSM: Specifies the sub-subassembly number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>SUBASSEM: Specifies the subassembly number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p>

## MIL-L-8031E (USAF)

## APPENDIX A

TABLE A-I. Tag Description - Continued.

Tag	Description
<b>&lt;mainisers&gt; - cont.</b>	<p>TEXTTYPE: Specifies a code which further identifies the element. The value of this attribute consists of a number. If no value is specified for this attribute, one may be implied by the system.</p> <p>TOCENTRY: Specifies whether the element will be included in the table of contents for the document. If the value is set to zero, the element will not be included in the table of contents. If any other value is given, the element will be included. The value of this attribute consists of a number. The default value of this attribute is "1".</p> <p>UNIT: Specifies the unit number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>VERIFIED: Specifies the verification status of the information. This information is used to build the verification status (&lt;verstat&gt;) page. If the value is set to zero, the information has not been verified. If any other value is given, the information has been verified. The value of this attribute consists of a number. The default value of this attribute is "0".</p>
<b>&lt;pubtype security = x&gt;</b>	<p><b>Publication Type</b></p> <p>Identifies the publication type.</p> <p>The publication type element requires a starting tag (&lt;pubtype&gt;) but does not require an ending tag.</p> <p>If the value of the "math" entity is set to "ignore", this element contains the following structure:</p> <ul style="list-style-type: none"> <li>a group of elements consisting of:</li> <li>parsed character data; or,</li> <li>one footnote reference (&lt;ftnref&gt;) element; or,</li> <li>one cross reference (&lt;xref&gt;) element; or,</li> <li>one index entry flag (&lt;indxflag&gt;) element; or,</li> <li>one verbatim text (&lt;verbatim&gt;) element; or,</li> <li>one emergency information (&lt;emergency&gt;) element; or,</li> <li>one change information (&lt;change&gt;) element; or,</li> <li>one emphasis (&lt;emphasis&gt;) element; or,</li> <li>one applicability (&lt;applicabil&gt;) element; or,</li> <li>one graphic (&lt;graphic&gt;) element; or,</li> <li>one subscript (&lt;subscript&gt;) element; or,</li> <li>one superscript (&lt;supscript&gt;) element; or,</li> <li>one external cross reference (&lt;extref&gt;) element; or,</li> <li>one data identification (&lt;dataiden&gt;) element;</li> </ul> <p>which may occur one or more times.</p> <p>If the value of the "math" entity is set to "include", this element contains the following structure:</p>

MIL-L-8031E (USAF)

## APPENDIX A

TABLE A-I. Tag Description - Continued.

Tag	Description
<pubtype> - cont.	<p>a group of elements consisting of:</p> <ul style="list-style-type: none"> <li>parsed character data; or,</li> <li>one footnote reference (&lt;ftnref&gt;) element; or,</li> <li>one cross reference (&lt;xref&gt;) element; or,</li> <li>one index entry flag (&lt;indxflag&gt;) element; or,</li> <li>one verbatim text (&lt;verbatim&gt;) element; or,</li> <li>one emergency information (&lt;emergency&gt;) element; or,</li> <li>one change information (&lt;change&gt;) element; or,</li> <li>one emphasis (&lt;emphasis&gt;) element; or,</li> <li>one applicability (&lt;applicabil&gt;) element; or,</li> <li>one graphic (&lt;graphic&gt;) element; or,</li> <li>one subscript (&lt;subscript&gt;) element; or,</li> <li>one superscript (&lt;supscript&gt;) element; or,</li> <li>one external cross reference (&lt;extref&gt;) element; or,</li> <li>one data identification (&lt;dataiden&gt;) element; or,</li> <li>one formula reference (&lt;dfref&gt;) element; or,</li> <li>one inline formula (&lt;f&gt;) element;</li> </ul> <p>which may occur one or more times.</p> <p>The publication type is part of the main series headings (&lt;mainseries&gt;), and the subseries headings (&lt;subseries&gt;).</p> <p>Source Paragraph: 3.2.2.2.3 - MIL-L-8031E</p> <p><b>Optional Attribute(s):</b></p> <p><b>SECURITY:</b> Specifies the level of security of the element. The value of this attribute may be set to one of the following values: "u" (Unclassified), "c" (Confidential), "s" (Secret). The default value of this attribute is "u".</p>



## MIL-L-8031E (USAF)

## APPENDIX A

TABLE A-I. Tag Description - Continued.

Tag	Description
<b>subseries</b> <b>applcrefid = x</b> <b>applctype = x</b> <b>assem = x</b> <b>assocfig = x</b> <b>assotab = x</b> <b>compon = x</b> <b>contype = x</b> <b>delchlvl = x</b> <b>esds = x</b> <b>hcp = x</b> <b>id = x</b> <b>inschlvl = x</b> <b>label = x</b> <b>lru = x</b> <b>module = x</b> <b>partno = x</b> <b>refdes = x</b> <b>security = x</b> <b>skilltrk = x</b> <b>sssn = x</b> <b>ssubassm = x</b> <b>subassem = x</b> <b>texttype = x</b> <b>unit = x&gt;</b>	<p>Identifies the subseries headings.</p> <p>The subseries headings element requires a starting tag (&lt;subseries&gt;) and an ending tag (&lt;/subseries&gt;).</p> <p>This element contains the following structure:</p> <ul style="list-style-type: none"> <li>one title (&lt;title&gt;) element; followed by,</li> <li>a group of elements consisting of: <ul style="list-style-type: none"> <li>one technical manual identification number (&lt;tmidno&gt;) element; followed by,</li> <li>one title (&lt;title&gt;) element; followed by,</li> <li>one publication type (&lt;pubtype&gt;) element;</li> </ul> </li> <li>which may occur one or more times.</li> </ul> <p>The subseries headings is part of the main series headings (&lt;mainsers&gt;).</p> <p>Source Paragraph: 3.2.2.1 - MIL-L-8031E</p> <p><b>Optional Attribute(s):</b></p> <p><b>APPLICREFID:</b> References unique identifier(s) assigned to applicability identifier(s) (&lt;applicid id="xxx"&gt;). The value of this attribute consists of a list of references to names previously entered as unique identifiers of other elements. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>APPLICTYPE:</b> This attribute references unique identifier(s) assigned to applicability definitions (&lt;applicdef id="xxx"&gt;). Although it is possible to derive the applicability type from the applicability reference identifier, it may be explicitly stated with this attribute. The value of this attribute consists of a list of references to names previously entered as unique identifiers of other elements. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>ASSEM:</b> Specifies the assembly number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>ASSOCFIG:</b> Identifies a figure associated with the element through the use of the "id" attribute in the figure (&lt;figure&gt;) element. The value of this attribute consists of a list of references to names previously entered as unique identifiers of other elements. If no value is specified for this attribute, one may be implied by the system.</p> <p><b>ASSOCTAB:</b> Identifies a table associated with the element through the use of the "id" attribute in the table (&lt;table&gt;) element. The value of this attribute consists of a list of references to names previously entered as unique</p>



MIL-L-8031E (USAF)

## APPENDIX A

TABLE A-I. Tag Description - Continued.

Tag	Description
<subsys> - cont.	<p>identifiers of other elements. If no value is specified for this attribute, one may be implied by the system.</p> <p>COMPON: Specifies the component number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>CONTYPE: Identifies the content type of the element. When used with steps, the implied value is procedural. When used with all other element types, the implied value is descriptive. The value of this attribute may be set to one of the following values: "desc" (Descriptive), "proc" (Procedural). If no value is specified for this attribute, one may be implied by the system.</p> <p>DELCHLVL: Specifies the change level(s) at which information was deleted. An audit trail can be maintained by listing multiple change levels separated by commas. The value of this attribute consists of a name where the first character is numeric. If no value is specified for this attribute, one may be implied by the system.</p> <p>ESDS: Electrostatic Discharge Sensitive parts - If the value is set to zero, the element does not contain information involving ESDS parts, components or circuits. If any other value is given, the element does contain information involving ESDS items. The value of this attribute consists of a number. The default value of this attribute is "0".</p> <p>HCP: Hardness Critical Process - If the value is set to zero, there is no hardness critical information. If any other value is given, the element contains hardness critical information. The value of this attribute consists of a number. The default value of this attribute is "0".</p> <p>ID: An identifier of the element which is assigned at origination and which remains unchanged as the document is revised or updated even though the automatically assigned enumeration or manually assigned "labels" change. The value of the "id" is used making references to the element from other portions of a document. If no "id" is given, none will be maintained and the element can then not be cross-referenced to by means of an IDREF on another element or with a cross-reference (&lt;xref&gt;). The value of this attribute defines a unique identifier for the element. If no value is specified for this attribute, one may be implied by the system.</p> <p>INSCHLVL: Specifies the change level(s) at which information was inserted. An audit trail can be maintained by listing multiple change levels separated by commas. The value of this attribute consists of a name where the first character is numeric. If no value is specified for this attribute, one may be implied by the system.</p> <p>LABEL: The label associated with the element (i.e. chapter number). This attribute is only appropriate for manually enumerated documents. Typically, the output system will automatically enumerate the elements requiring</p>

MIL-L-8031E (USAF)

## APPENDIX A

TABLE A-I. Tag Description - Continued.

Tag	Description
<subsys> - cont.	<p>enumeration, in which case this attribute would be omitted. The value of this attribute consists of a name where the first character is alphanumeric. If no value is specified for this attribute, one may be implied by the system.</p> <p>LRU: Specifies the line replaceable unit (LRU) number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>MODULE: Specifies the module number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>PARTNO: Specifies the equipment part number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>REFDES: Specifies the appropriate reference designator associated with the information. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>SECURITY: Specifies the level of security of the element. The value of this attribute may be set to one of the following values: "u" (Unclassified), "c" (Confidential), "s" (Secret). The default value of this attribute is "u".</p> <p>SKILLTRK: Designates the skill level of the user at which the information in this element is aimed. The value of this attribute consists of a list of names where the first character of each name is alphanumeric. If no value is specified for this attribute, one may be implied by the system.</p> <p>SSSN: Specifies the system/subsystem/sub-assembly (SSSN) code associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>SSUBASSM: Specifies the sub-subassembly number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>SUBASSEM: Specifies the subassembly number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p> <p>TEXTTYPE: Specifies a code which further identifies the element. The value of this attribute consists of a number. If no value is specified for this attribute, one may be implied by the system.</p> <p>UNIT: Specifies the unit number associated with the element. The value of this attribute consists of character data. If no value is specified for this attribute, one may be implied by the system.</p>

# STANDARDIZATION DOCUMENT IMPROVEMENT PROPOSAL

## INSTRUCTIONS

1. The preparing activity must complete blocks 1, 2, 3, and 8. In block 1, both the document number and revision letter should be given.
2. The submitter of this form must complete blocks 4, 5, 6, and 7.
3. The preparing activity must provide a reply within 30 days from receipt of the form.

NOTE: This form may not be used to request copies of documents, nor to request waivers, or clarification of requirements on current contracts. Comments submitted on this form do not constitute or imply authorization to waive any portion of the referenced document(s) or to amend contractual requirements.

### I RECOMMEND A CHANGE:

1. DOCUMENT NUMBER  
MIL-L-8031E(USAF)

2. DOCUMENT DATE (YYMMDD)  
10 May 1991

3. DOCUMENT TITLE  
LIST OF APPLICABLE PUBLICATIONS (LOAP), PREPARATION OF

4. NATURE OF CHANGE (Identify paragraph number and include proposed rewrite, if possible. Attach extra sheets as needed.)

5. REASON FOR RECOMMENDATION

### 6. SUBMITTER

a. NAME (Last, First, Middle Initial)

b. ORGANIZATION

c. ADDRESS (Include Zip Code)

d. TELEPHONE (Include Area Code)

7. DATE SUBMITTED  
(YYMMDD)

(1) Commercial

(2) AUTOVON  
(if applicable)

### 8. PREPARING ACTIVITY

a. NAME

HQ AFLC/ENCS

b. TELEPHONE (Include Area Code)

(1) Commercial

(2) AUTOVON

c. ADDRESS (Include Zip Code)

WRIGHT-PATTERSON AFB, OH 45433-5000

IF YOU DO NOT RECEIVE A REPLY WITHIN 45 DAYS, CONTACT:

Defense Quality and Standardization Office  
5203 Leesburg Pike, Suite 1403, Falls Church, VA 22041-3466  
Telephone (703) 756-2340 AUTOVON 289-2340

**INSTRUCTIONS:** In a continuing effort to make our standardization documents better, the DoD provides this form for use in submitting comments and suggestions for improvements. All users of military standardization documents are invited to provide suggestions. This form may be detached, folded along the lines indicated, taped along the loose edge (*DO NOT STAPLE*), and mailed. In block 5, be as specific as possible about particular problem areas such as wording which required interpretation, was too rigid, restrictive, loose, ambiguous, or was incompatible, and give proposed wordin, changes which would alleviate the problems. Enter in block 6 any remarks not related to a specific paragraph of the document. If block 7 is filled out, an acknowledgement will be mailed to you within 30 days to let you know that your comments were received and are being considered.

**NOTE:** This form may not be used to request copies of documents, nor to request waivers, deviations, or clarification of specification requirements on current contracts. Comments submitted on this form do not constitute or imply authorization to waive any portion of the referenced document(s) or to amend contractual requirements.

---

(Fold along this line)

---

(Fold along this line)

DEPARTMENT OF THE AIR FORCE



NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

OFFICIAL BUSINESS  
PENALTY FOR PRIVATE USE \$300

**BUSINESS REPLY MAIL**

FIRST CLASS PERMIT NO. 73238 WASHINGTON D. C.

POSTAGE WILL BE PAID BY THE DEPARTMENT OF THE AIR FORCE

HQ AFLC/ENCS  
WRIGHT-PATTERSON AFB, OH 45433-5001

